



# Maid Labs TECHNOLOGIES

## VOLUCALC™ HYBRID CS

### User Manual

Real Time Volumetric Flow Meter for Lift Stations with Constant Speed pumps, Real Time Diagnostic, Open Channel Flow Meter



Thank you for purchasing the VOLUCALC™ HYBRID CS.

## Contacts

### **MAID Labs Inc.**

944, André-Liné, Granby, Québec, Canada, J2J 1E2, T 450-375-2144 Toll-Free USA-Canada : 855-875-2144

Web : [www.maidlabs.com](http://www.maidlabs.com) Email : [info@maidlabs.com](mailto:info@maidlabs.com)

## Use the MAID Device Configuration software to setup this instrument

Note: The VOLUCALC™ HYBRID CS was designed to be programmed and setup by the MAID Devices Configurator software. Please visit MAID Labs website ([www.maidlabs.com](http://www.maidlabs.com)) section Volucalc HYBRID CS, VS or RT to download the latest version of the Configurator or copy the following link to your browser:

[www.maidlabs.com/wp-content/uploads/files/maiddevicesconfigurator.zip](http://www.maidlabs.com/wp-content/uploads/files/maiddevicesconfigurator.zip).

This software has many features and libraries which allows the reuse of standard pump curve data for different stations. However, minor changes to the Volucalc HYBRID CS setup can be accomplished through the display screen by following the prompts.

## Warranty





MAID Labs Technologies Inc. (hereinafter called "MAID Labs") states the following warranty for any new Maid Labs product, sold by our authorized representatives.

MAID Labs guarantees that this product, under normal use and maintenance is free of all manufacturing defects, and is subject to the following terms and conditions:

1. To obtain warranty service:
  - (a) The product was registered on Maid Labs Web site within 30 (thirty) days from the date of receipt.
  - (b) The product must be shipped to Maid Labs main office or to an approved maintenance and repair service center for repair or replacement. Shipping is at the customer's expense.
2. Limitations: This warranty does not apply to:
  - (a) Repair or replacement of all cabinets, batteries, connecting wires, antennas and accessories.
  - (b) Any defect or repair as a result of abuse, neglect, inadequate care and/or misuse.
  - (c) Any defect or repair due to failure to follow the recommendations in the user manual.
  - (d) Any modification, adjustment or repair to Maid Labs products by any other company other than Maid Labs authorized maintenance and repair centers.
  - (e) All Maid Labs products, whose serial number has been damaged, altered or removed.
  - (f) All Maid Labs products that are not the property of the original owner.
  - (g) Products purchased from a bankrupt, insolvent or non-approved representative.
  - (h) Any damages caused by fire, rain, flood, lightning, power surges or other events beyond the control of Maid Labs (acts of God).
  - (i) The warranty does not cover the elimination of static or electrical interference, adjustments or costs of labor associated with removal or reinstallation of the unit for repairs.
  - (j) The warranty does not cover damage caused by high humidity, water or leaking/damaged batteries.
3. If a Maid Labs product is defective under applied conditions, necessary repairs will be performed, at no additional cost, for parts and labor where Maid Labs recognizes that such defects are caused by materials or manufacturing.
4. This warranty constitutes the entire expressed warranty given by Maid Labs for Maid Labs products. No representative or service maintenance employee is authorized to extend this warranty on behalf of Maid Labs
5. Since each installation may incorporate malfunctions, preventing Maid Labs from ensuring the smooth operation of its devices in all circumstances, Maid Labs will not refund nor exchange the instruments that were caused by connections to any problematic installation.
6. The warranty period is three years on parts and labor from the date of shipment.
7. LIMITATION OF DAMAGES: To the extent permitted by applicable law, under no circumstances MAID Labs or its affiliates be liable to you, to a user or a third party for any indirect, special, consequential, or punitive damages of any kind whether in contract or civil, including but not limited to, personal injury, loss of revenue, loss of goodwill, loss of business opportunities, loss of data, whatever may have been the predictability of such damages. And in no case may the total responsibility of Maid Labs or its affiliates exceed the equipment purchase price received from you, from a user or from a third party, regardless of the laws by which the cause of action was brought. The foregoing does not affect your territory's statutory rights.

At Maid Labs Technologies, we have made every effort to provide a user manual that is up to date and easy to use. However, it is possible that errors may occur, or recent hardware or software upgrades might not be in your manual. We strongly suggest checking our website to see if a newer version of the manual is available [www.maidlabs.com](http://www.maidlabs.com).

## Table of contents

<b>CONTACTS</b>	<b>2</b>	OPEN CHANNEL FLOW EQUATIONS (OVERFLOW)	33
<b>USE THE MAID DEVICE CONFIGURATION SOFTWARE TO SETUP THIS INSTRUMENT</b>	<b>2</b>	BANDWIDTH SETUP	33
<b>WARRANTY</b>	<b>3</b>	ALARMS SETUP	33
<b>TABLE OF CONTENTS</b>	<b>4</b>	DOWNLOAD SETTINGS	34
<b>PRODUCT DESCRIPTION</b>	<b>6</b>	RESET TOTAL EVENTS	34
<b>PRODUCT APPLICATION</b>	<b>6</b>	FIRMWARE UPGRADE	34
CONSTANT SPEED PUMPS FLOW METER	6	LANGUAGE	35
VARIABLE SPEED PUMPS FLOW METER	<b>ERREUR ! SIGNET NON DEFINI.</b>	LOCK SCREEN PASSWORD	35
OPEN CHANNEL FLOW METER	6	PRESSURE OVERRIDE AND LEVEL OVERRIDE	35
VOLUCALC HYBRID CS DETECTS PROBLEMS IN LIFT STATIONS	6	PUMP CAPACITIES	35
VOLUCALC™ HYBRID CS SAVES ENERGY	6	PUMP RATIO	35
<b>VOLUCALC™ HYBRID CS – INSTALLATION</b>	<b>6</b>	REPORT OPTIONS	35
BEFORE GOING TO THE LIFT STATION:	7	TECHNICIAN	35
WHEN ARRIVING AT THE LIFT STATION:	7	FACTORY RESET	36
THE VOLUCALC HYBRID CS CONNECTORS	8	DELETE FILE	36
ACCESSORIES SELECTION CHART	9	SD CARD INFO	36
<b>CONNECTIONS</b>	<b>10</b>	<b>DEVICE INFO</b>	<b>36</b>
<b>CONFIGURATION OF A LIFT STATION.</b>	<b>12</b>	<b>IP INFORMATION</b>	<b>36</b>
WHEN CONFIGURATION IS READY	24	<b>COMMUNICATION TEST</b>	<b>36</b>
<b>VOLUCALC HYBRID CS MENU FLOWCHARTTCP/IP</b>		<b>RELAY TEST</b>	<b>36</b>
<b>MODBUS TABLE</b>	<b>25</b>	<b>ANALOG OUTPUT TEST</b>	<b>37</b>
<b>PHYSICAL SPECIFICATIONS</b>	<b>28</b>	<b>LOCK SCREEN</b>	<b>37</b>
<b>DIMENSIONS</b>	<b>29</b>	<b>SHUTDOWN OR REBOOT DEVICE</b>	<b>37</b>
<b>COMMUNICATION</b>	<b>30</b>	<b>RT  (REAL TIME)</b>	<b>37</b>
<b>SCREENS</b>	<b>30</b>	REAL TIME	37
<b>MAIN SCREEN</b>	<b>30</b>	PUMP STATISTICS	38
<b>NUMBERS SELECTION SCREEN</b>	<b>31</b>	POWER CONSUMPTION	38
<b>MENU </b>	<b>31</b>	INTERNAL INFO	38
<b>CONFIGURATION MENU</b>	<b>31</b>	RAIN STATISTICS	38
DATE & TIME SETUP	32	<b>INFO </b>	<b>39</b>
UNITS	32	<b>USB </b>	<b>39</b>
DISPLAY	32	REPORTS	40
INPUTS/OUTPUTS	32	COPY USER MANUAL	41
LEVEL SETUP	33	MERMAID / TECH DATA	41
CHANNEL FLOW (OVERFLOW) SETUP	33	COPY CONFIG TO USB	41
		<b>MAID DEVICES CONFIGURATOR</b>	<b>42</b>
		WELCOME WINDOW	42
		OPTIONS	43
		DEVICE DETAILS	43

GENERAL INFORMATIONS	44
DISPLAY OPTIONS	44
LIFT STATION	45
INPUTS AND OUTPUTS	46
FIXED SPEED PUMP CAPACITY	49
PUMP CURVE SELECTION	50
PUMP CURVE EDITOR	52
VOLUCALC™ HYBRID CS CALIBRATION WORKSHEET	55
LEVEL SETUP	56
FLOW COMPUTATION FORMULAS	57
CONTRACTED RECTANGULAR WEIR AND SUPPRESSED	
RECTANGULAR WEIR	57
TRAPEZOIDAL WEIR (CIPOLETTI)	58
V NOTCH WEIR	58
MANNING EQUATION (OPEN CHANNEL)	58
MANNING EQUATION (PARTIALLY FULL PIPE)	59
PARSHALL WEIR	60
PALMER-BOWLUS WEIR	60
LEOPOLD-LAGCO WEIR	60
POLYNOMIAL FLOW FORMULA	61
STANDARD FLOW FORMULA	61
LOOKUP TABLE	62
CALIFORNIA PIPE	62
WELL DIMENSIONS	63
EXTERNAL BATTERY	64
ALARMS	65
COMMUNICATION SETUP	66
REPORT OPTIONS	67
SAVE FOLDER	67
CURRENT SENSOR (MLCT75)	68
CURRENT SENSORS (MLCT150 AND MLCT300)	68
PANEL DOOR BRACKETS (MLSUPPANEL)	69
DIN RAIL BRACKETS (MLSUPDIN)	69
<b>INDEX</b>	<b>70</b>

## Product Description

VOLUCALC™ HYBRID CS is a volumetric flow meter and an open channel flow meter and can be used on lift stations having constant speed pumps.. A rain gauge can also be connected, for infiltration studies.

## Product Application

### Constant speed pumps flow meter

To be used as a volumetric flow meter, the lift station dimensions are entered in the Volucalc Hybrid CS. The instrument calculates the time it takes for the liquid to rise and fall between these levels and calculates a volumetric flow every 30 seconds or faster within 2% of accuracy. As soon as a calculation is performed, the computed flow is displayed on the screen of the instrument, the cumulative volume is updated and the 4-20 mA analog output is adjusted. When pump signals are the only means to detect when start and stop levels are reached, then flows can only be calculated at the end of a filling cycle and pumping cycle.

### Open Channel Flow Meter

The VOLUCALC™ Hybrid CS can measure flow from many different open channels and generic equations. This means the volume of water coming in balance the volume pumped and the volume derived to another overflow conduit.

### Volucalc Hybrid CS Detects Problems in Lift Stations

Simply install the VOLUCALC™ Hybrid CS and look at the generated alarm on the screen or in the monthly report of the device to detect abnormal events.

### *VOLUCALC™ Hybrid CS Saves Energy*

Volucalc Hybrid CS can suggest the best pump to use at the right time in order to maximize the energy efficiency of the lift station. Running the most efficient pump when inflow is normal or high, and to run the less efficient pump when inflow is lower can save quite a lot on the electrical bill.

## VOLUCALC™ Hybrid CS – Installation

It is the user's responsibility to ensure that this product is not exposed to an environment for which it is not designed. These conditions may include a range of extreme operating temperatures, high humidity, vibration or abnormal shock, submersion or potentially explosive atmospheres.

Periodic cleaning is recommended for the sensors to prevent fouling and ensure they are providing the correct data. It is important to follow the sensor manufacturer's recommendations. Most of the time, Volucalc Hybrid CS uses the existing level sensor and a current isolator to protect the control and Volucalc against each other in case of malfunction.

Each Maid Labs product is designed to operate correctly within a specific range of electrical conditions. The product label identifies the main parameters for all connections. All input connections are designed to resist the reverse polarity, as well as a higher voltage to a certain extent. It is the user's responsibility to ensure that all electrical connections are made in accordance with the recommendations of MAID Labs and the local electrical code. **The user should read this manual before connecting the device.**

The VOLUCALC™ Hybrid CS is not waterproof. Avoid placing it in wet locations where liquids could enter the product or where condensation is a problem. Damage caused by water or excessive humidity voids the Maid Labs

warranty. The instrument must be placed in a location where there is no risk of being hit or dropped. A label might be supplied to cover the Ethernet port to minimize the risk of damaging the port from insects or infiltration, but if not supplied, the user can install one..

### *Before going to the lift station:*

- The sensors should be selected using the Quotation Form of page 9
- Pumps information that is needed:
  - How many pumps in the lift station. Are they fixed speed or variable speed pumps? CS is only for constant speed pumps.
  - Power or current consumption per phase. A good rule of thumb is 1A per horsepower at 480 volts.
  - Operating voltage.
  - Optional: Make and model of the pumps.
  - Pump capacity is useful to compare the results but not required.
- The lift station must have a receptacle to plug the 12V to 24V DC supplied power supply.


With this information, select the quantity and the proper current sensors for the fixed speed pumps. The default current sensor is MLCT75 that can be configured for 15A or 75A range. If the average current is over  $\frac{3}{4}$  of the range of the sensor, we recommend using a bigger sensor.

- Station Information
  - How the station is working. How pumps start and stop.
  - What is the wet well dimension? The lift station construction (blueprint) plan is ideal.
  - Where is located the inflow pipe and if there is any overflow pipe.
  - Is there a level sensor at the lift station that the device can connect to? If yes, what is the make and model? If not, do you want to install one? Is there a pressure sensor at the lift station that the device can connect to? The use of a level sensor is optional.
- A USB key and a computer with the free Maid Devices Configurator software (available on [www.maidlabs.com](http://www.maidlabs.com)) installed and required to configure the device. A USB thumb drive is supplied with the Volucalc
- If using Maidmaps SCADA software
  - The address of the lift station (to position the device on the map of Maidmaps)
  - Configure the device on Maidmaps before installation.

### *When arriving at the lift station:*

1. Find an appropriate location to install the Volucalc Hybrid CS. The device needs to be near the pumps power cables to install the current clamps if not, the current clamp cable can be extended by the person doing the installation. The Volucalc Hybrid CS require 12-24 VDC 2A. The provided power supply can be used or any other stable power source. If a cellular modem is used, reserve a place for it and ideally install the antenna outside of the control panel.
2. Prepare all the necessary connexions to the inputs and outputs. Do not connect to the Volucalc Hybrid CS yet.
3. Double check the pump start and stop level if not connected to an analog level sensor. If a level sensor is used, check its readings.
4. Prepare the configuration with the MaidDevice Configurator, save it on a USB drive and program the Volucalc Hybrid CS.

## The Volucalc Hybrid CS connectors





## Accessories Selection Chart

# Volucalc Hybrid™ QUOTATION FORM

**SELECT WHAT YOU NEED** (Check the items that you want us to quote on)

V	C	<b>Pumps' type</b>	Variable <b>MLVC-VS</b> or Constant <b>MLVC-CS</b>		
---	---	--------------------	--	--	--

1	2	<b>Number of pumps</b>	<b>Number of current sensors required</b>	<b>Specify</b>
3	4	1, 2, 3 or 4	1 per pump	Pump size (HP) or current per leg

Current sensors (select size and quantity for each pump station)				
	Pump size or better, current of one leg	Part number	Range	Description
<input type="checkbox"/>	For pumps between .5 HP and 40 HP	<b>MLCT75</b>	75 Amps	Mini current sensor 75 Amps
<input type="checkbox"/>	For pumps between 40 HP and 100 HP	<b>MLCT150</b>	150 Amps	Current sensor 150 Amps
<input type="checkbox"/>	For pumps between 100 HP and 250 HP	<b>MLCT300</b>	300 Amps	Current sensor 300 Amps
<input type="checkbox"/>	For pumps between 250 HP and 1000 HP	<b>MLCTP1500</b>	1500 Amps	Current sensor 1500Amps

Level sensors - The existing system can be used if available				
Not required for constant speed pumps, unless Real Time Flow is wanted. <i>Cable length must be specified.</i>				
	Type	Part number	Range	Description
<input type="checkbox"/>	Ultrasonic	<b>MLUS-6M</b>	6 m / 19.7 ft	Ultrasonic level sensor (deadband 0.6 m / 2 ft)
<input type="checkbox"/>	Pressure	<b>MLPLR</b>	Adjustable	Level pressure sensor for wastewater lift station

Communication	Part number	Service	Description
<input type="checkbox"/> Cellular	<b>MLCELETH</b>	By Maid Labs	Cellular modem with Ethernet port
<input type="checkbox"/> Wifi	<b>MLWIFIPICO</b>		WiFi interface module
<input type="checkbox"/> Others	<b>Volucalc Hybrid™</b> can communicate through most TCP/IP compatible hardware		

Other accessories	Part number	Description
<input type="checkbox"/> Force main pressure gauge	<b>MLPSVL</b>	100 PS1 Pressure sensor (cable 5 m / 16 ft).
<input type="checkbox"/> Rain Gauge	<b>MLRG</b>	National Weather Services approved. 0.01" (0.254mm) per pulse
<input type="checkbox"/> NEMA4X enclosure	<b>MLENCHMD-TR</b>	With transparent cover (-TR), with opaque cover (-GR)
<input type="checkbox"/> Front panel door bracket	<b>MLSUPPANEL</b>	Brackets to fix <b>Volucalc™</b> on panel door
<input type="checkbox"/> DIN Rail brackets	<b>MLSUPDIN</b>	Brackets to fix <b>Volucalc™</b> on Din Rail

MaidMaps SCADA Web Application	
	<b>Part Number- Number of years</b>
<input type="checkbox"/> Basic	MLMAPSBASIC-1 or -3 or -5
<input type="checkbox"/> Plus	MLMAPSPUS-1 or -3 or -5
<input type="checkbox"/> Cellular Services	MLCELDATA
<input type="checkbox"/> Cellular Activation	MLCELDATA-ACT

Watt Meter (select model based on electrical service types. Call Maid Labs if your application is not listed)				
Part number	Vac Line to Neutral	Vac Line to Line	Neutral Required	Comments
<input type="checkbox"/> <b>MLWM208Y</b>	120	208-240	YES	Mostly for 1 phase 120 Volts pumps
<input type="checkbox"/> <b>MLWM600Y</b>	347	600	YES	Common in Canada
<input type="checkbox"/> <b>MLWM240D</b>	N/A	208-240	NO	Mostly for 1 phase 240 Volts pumps
<input type="checkbox"/> <b>MLWM480D</b>	N/A	400-480	NO	Common in USA

High Accuracy Current Sensors Only for Watt Meter (Call Maid Labs if your application is not listed)			
	Pump size or better, current of one leg	Part number	Range
<input type="checkbox"/>	For pumps between .5 HP and 20 HP	<b>MLHACT25</b>	25 Amps
<input type="checkbox"/>	For pumps between 20 HP and 80 HP	<b>MLHACT100</b>	100 Amps
<input type="checkbox"/>	For pumps between 80 HP and 200 HP	<b>MLHACT250</b>	250 Amps

## Connections

### 4-20 mA current loop (for anything monitored this way)

There are 3 options: These drawings show the connection of an existing 4-20 mA analog level sensor. Other types of sensors can be connected to this input (or any unused analog inputs) if no level monitoring is done.


#### RECOMMENDED METHOD A (Drawings to the Right)

Add an in-line 250 ohms precision resistor in the current loop. Connect the Volucalc Hybrid CS in parallel of the resistor and configure the level input in “4-20mA sensor through resistor” mode.

This drawing shows a connection to the Pressure analog input. Something else than pressure can be connected to this input, if no pressure monitoring is done.

#### RECOMMENDED METHOD B (Drawing Below)

Insert a 4-20 mA signal isolation device. See description at page 69.




#### ANOTHER WAY (Drawings to the Right)

Insert the Volucalc Hybrid CS level input in-line in the current loop.

Advantages: High precision. Inconvenient: If the Volucalc Hybrid CS reboot or is disconnected, the current loop is broken. The Volucalc Hybrid CS cannot share same power ground as the PLC.






### Cellular modem power with battery backup

It's recommended using the 12v output and to connect the cellular modem through the Relay 1 out (and configure this output to "Ethernet control") so this way, the Volucalc Hybrid CS can manage the power to the modem independently of the level sensor during power failure or if the modem needs to be reinitialized.



### 3 wire ultrasonic level sensor.

When using a 3-wire analog level sensor, most of the time, it's because the level sensor need 12VDC to operate, which are 12v, ground and a wire for the output signal (typically 0-10v or 4-20 mA).



## Duplex, Triplex and Quadruplex Constant Speed Pumps

The most common constant speed pump configuration is one current sensor per pump. This connection drawing shows where to connect the current sensors for a duplex lift station. One sensor per pump connected to the appropriate pump input, on the right hand side of the instrument. The unused pump input sensors can be used as standard analog input and will be recorded every second.

If mini current sensors (MLCT75) are used for pumps of less than 10 HP, then the DIP switches should be moved left with a very small screw driver or a paper clip to adjust the setting of the current clamp to 15 Amps.



If mini current sensors (MLCT75) are used for pumps of less than 40 HP, then the DIP switch should be centered. If the size of the pumps is above 40 HP or if the inputs are used for generic analog inputs, then the DIP switches should be placed to their most right position.

Pump 1	Pump 1 (phase 1)	CT 75A
Pump 2	Pump 2 (phase 1)	CT 75A
Pump 3	Not used	
Pump 4	Not used	

In the Inputs and Outputs dialog of the MaidDevices Configurator software, the pumps inputs setup on the left is standard for a duplex pump station. The size of the current sensor can be changed easily. Don't forget to change the position of the DIP switches if required.

CT 75A

CT 150A

CT 15A

CT 300A

CT 75A


Custom current

## Configuration of a lift station.


To create a new configuration for the Volucalc Hybrid CS a computer with the free MaidDevices Configurator software is required. This software can be downloaded from the Web page of the Volucalc Hybrid CS at [www.maidlabs.com](http://www.maidlabs.com).

Start the software and click **Create a new File.**

Select the Volucalc Hybrid CS icon and enter the serial number of the device that you are doing the setup for.



The **Units** can be changed by clicking on **Units ...** in the lower left corner of the dialog. To change them all rapidly, click on **United States** or **International** at the top of the dialog.



The name given is used to identify the monthly reports copied to the USB drive or downloaded remotely with the free scada software maidMaps.

Select the Power source


☒ **AC adapter** is the most common configuration for lift stations.

Ethernet communications:

**None** – Should be clear

**Standard** – Any communication devices including cellular modems if it is not connected like below.

**Cellular Modem** - If the mode m is connected like this:



Set the language, time zone and display options. You can protect the device with a 5 digit password if needed.

This next dialog is to select the quantity and type of pumps, the flow algorithm used and electrical parameters.

A large choice of flow algorithms is available. They are related to the type of pump selected.

**MaidDevices Configurator**

**General informations**

Identification  
 Device Name: Station 1 Serial number: RT146000

Power source  
☐ AC adapter  
☒ AC with battery backup  
☐ External battery  
☐ Internal batteries only

Ethernet communications  
☐ None Not connected  
☒ Standard Wired network  
☐ Cellular modem Controlled power source

**MaidDevices Configurator**

**Display options**  
 Display setup and backlight options

Regional settings  
 Language: English  
 Time zone: (UTC-05:00) Est (É.-U. et Canada)

Display  
 Brightness: 20 %

Battery operation  
 Time before backlight close: 10 s  
 Time before screen close: 30 s

Password  
☐ Protect device with a password:  
 Confirm password:

Options... Units... Back Next Cancel



## Flow algorithm

**None** - the Volucalc Hybrid CS won't do any type of flow computation.

**External flow** – The Volucalc Hybrid CS will read the flow from an external flow meter, like a mag meter. Any unused analog input can be used to get the “Measured inflow or measured outflow”, as setup in the Inputs and Outputs dialog of the MaidDevices Configurator software.

**Fixed pump capacities** – A dialog will allow to enter pump capacities for each pump and combinations of pumps. The volume passing through the station is based on those capacities multiplied by their run times.

**Pump curves** – Pump curves are entered, instead of pump capacities. The calculated outflow is affected by the head (which is affected by the level and the force main pressure). If any of these two elements are missing, the real time accuracy will be lower.

**Volumetric** – **Good for fixed speed pumps** - This is based on the volume between the start and stop levels of the pumps. A dialog allows entering the shape of the well, its dimensions and levels calculated from the bottom of the well, the top of the well, or between the levels. For odd shapes, a volume can be entered. Flow when the pumps are off is based on the time it takes to fill the calculated volume. If the calculated flow rate is abnormal, then another algorithm must be used. Calculating the flow rate in and out of the station while the pumps are on requires a more complicated algorithm because sometimes, the pumps do not start or stop at their usual levels or the results seems abnormal. In these cases, other algorithms must be automatically selected.

**Volumetric with level sensor** – **Best for fixed speed pumps** - This When an analog level sensor is used and the shape of the well is constant, and then only the area of the well is required. In this configuration, Real Time Flow is calculated every time the level rises or falls by 2 inches or every 30 seconds or every time a pump start or stop.

## Electricity


**Phases** - The preset is 3 since most pumps used in collection system are 3 phases pumps.


**Average voltage** – This is to calculate the power consumption in kWh. Measured in delta means that the voltage is calculated between the phases and not compared to the ground.

**Power factor** – This is also used to calculate the power consumption in kWh. This is a value usually found on the electrical bill. If you don't know it, use 0.9.

**Cost per kWh** – Another information found on the electrical bill. Volucalc uses it to estimate the cost of inefficient pumps.

**Greenhouse gas** – This is used to transform the wasted energy caused by inefficient pumps into gas.







Current clamps are used to monitor the states of the pumps and their current. The input must be set to their right value by clicking on the sensor's displayed value. With fixed speed pumps, the input number represents the Pumps number. With variable speed pumps, the input number is right for the RPM monitoring, but not the current sensors as you see on the dialog on the right.

Also, DIP switches relate to the sensors size to set on the instrument. Read page 11 on that subject.

If a level sensor is used, a predefined model or custom sensor can be selected. The custom Sensor Setup dialog opens when clicking on the range of the sensor. The type of input and range can be entered.



The **Auto-calibrate** option is used when the range of the level sensor is unknown. Simply connect the level sensor to the Volucalc Hybrid CS and in the **Operation mode** dialog, specify the start and stop level of a pump. The first time the Volucalc Hybrid CS boot, it will wait for a pump start and a pump stop at precisely at the moment, it will record the value on the level input and compute a linear equation between the 2 points to generate a level input configuration that match the actual sensor.

**MaidDevices Configurator**

**Level setup**  
Specify the level reported by the sensor for which you want to display a value of 0 and the overflow level.

**Zero level adjustment**  
Enter the following measures:

From sensor to water:  ft

Flow depth:  ft

Or the measure between sensor and

Displayed zero:  ft

**Other measures**

☐ Overflow level:  ft

☒ Fast reading:  ft  
Threshold before overflow (on external battery)

**Preview**

Sensor (ft) System (ft)

Bottom  
Water depth  
Sensor range  
Sensor position

Options... Units... ≤ Back Next ≥ Cancel

If a level sensor is configured at the **Inputs and outputs page**, the Level setup dialog will be displayed and a graph will show the range of the sensor with other options like the possibility to record sewage sewer overflow events including volume lost during the event.



The **Well dimensions** dialog appears when **Volumetric** or **Volumetric with level** is selected.

**Volumetric with level sensor** is the best most accurate method to calculate flow. It is based on the lift station's dimensions and the analog level sensor measurements. Volucalc Hybrid CS computes the inflow in Real Time, which is every 2 inches or 30 seconds.

**Well dimensions**  
Allows to specify geometry and dimensions of the well.

Geometry  
Geometry: Rectangle

Dimensions  
a:  ft  
b:  ft

General dimensions  
☐ Well depth:  0.000 ft Distance between top and zero level

Options... Units... Back Next Cancel

If **Volumetric** is selected, the **Operation mode** dialog is displayed at the next page, which allow entering the distances for the levels according to the selected distance method used. Enter all the values required. For very odd shapes, a volume can be entered.

**Operating mode**  
Allows to indicate pumps starts and stop levels.

Operating mode: One start level per pump and a common stop level Customize

Measurement method: Volume from top

States:

- Distance between levels
- Distance from bottom (zero level)
- Distance from top
- Volume between levels
- Volume from bottom (zero level)
- Volume from top

	Volume (US gal.)
Start of second pump	10.00
Start of first pump	11.00
Stop of all pumps	15.00

Options... Units... Back Next Cancel

If **Fixed pump capacities** is the selected **Flow algorithm**, the dialog to the right appears and allows to enter the capacities for each pump and each combination, but this last one is optional. If the pump combinations are unknown, pump ratio can be used like 75% of total flow for 2 pumps.

**MaidDevices Configurator**

**Pumps capacities**  
Allows to specify pumps combination flows.

Combinations flows:

P1	P2	Pumps	Flow
On	Off	1	500.0
Off	On	2	500.0
On	On	1 and 2	

☐ Allows the device to update capacities

Default combinations ratios

2 pumps:  %    3 pumps:  %    4 pumps:  %

Options...   Units...   ≤ Back   Next ≥   Cancel

**Pumps curves** can be used as the **Flow algorithm** for fixed and variable speed pumps. Other than being connected to an external flow meter, this is the only mean to calculate the flow out of variable speed pumps.

The Volucalc Hybrid CS will compute the outflow from the entered pump curves. It is possible to use up to 4 pumps, with fixed or variable speed in this mode. If less than 3 variable speed pumps are used, it's possible to record global current, as seen on this image. If 2 pumps are used, it's possible to record the current of each pump individually.

Optionally, a level sensor and a force main pressure sensor can be connected to the Volucalc Hybrid CS in order to compute the flow from the real head to increase accuracy. A constant head can also be specified.

## Pump Curves


Programming pump curves is the same for fixed and variable speed pumps.

Check ☒ Share curves for all pumps when all pumps are identical and only the first pump field needs to be configured.

Once a pump curve is created with the Configurator, all other Volucalc Hybrid CS configuration will have access to it. Therefore it is important to give the curve a meaningful name. To select an existing curve, simply click on the drop down selector.

The pump curves represent flow rate relative to head, which is a length. Contrary to constant speed pumps, variable speed pumps have several curves in the graph for multiple rotation speed (RPM). Note: Before creating curves in the Configurator, it is important to have these curves in the computer in a graphic format. The pump curves images should be displayed in a large format like in the following example that can be used to practice.

## EXAMPLE OF PUMP CURVE : MODEL INTELLIFLO



Once the pump curves is displayed on the screen of the computer (picture above), in the **Pump curves** area, click [Create ...](#) for the corresponding pump and the **Pump Curves Setup** dialog window will appear.

Use the same units as the graph, even if it is only temporarily. The Configurator does the conversion. Click on the [Options...](#) link, in the lower left corner of the dialog to change the units.

When the diameter of the impeller is known, it can be entered as part of the curve. If a different impeller diameter is used and entered in the **Pump Curve Selection** dialog (previous page), then the calculated flow will be automatically adjusted according to updated data on the impeller's diameter.

The **Pump Curves Setup** dialog box contains the following information:

- Information:**
  - Name: Intelliflo Model X
  - ☒ Impeller diameter: 1.000 ft
- Chart display:**


	Minimum	Maximum	Interval	Unit
Head:	0.000	120.000	20.000	ft
Flow:	0.0	160.0	20.0	GPM (US)
Initial curve speed:	3,450.0			RPM
- Buttons:** Options..., Advanced..., OK, Cancel

To create pump curves, enter the minimum and maximum values for the X-axis (flow) and Y (head) from the pump curve graph (like on the previous page) and the value of the intervals in the appropriate fields. Set a speed at which the first curve will be created in the **Initial curve speed** field. Start by the highest RPM curve.

The **Pump Curve Editor** provides a semi-transparent window to overlay and copy curves. Stretch the editor's transparent window over the manufactures pump curves graph until both scales match. The original pump curve document might need to be zooming in if too small.

Opacity  
70 %


You may want to adjust the opacity of the window of the overlay screen. The smaller percentage of opacity makes the window more transparent.



When overlapping the windows, be sure to use identical scales and adjust the window size for a perfect overlay of the graph of the pump curve document. Place the origin of the axes over each other to start and stretch the top right sides of the **Pump Curve Editor**.

After the axes and intervals are properly aligned, align the pointer of the mouse to the absolute left of the curve related to the Pump speed. Double-click the mouse left button to create a first point at zero flow (the x-axis is zero) for the RPM entered in the previous screen (shown in the upper left corner of the curve editor). Create a second point in the middle of the curve and a third and final point at the end of the curve. A curve connecting the three points will be at the screen. If necessary, add additional points on the curve to an almost perfect superposition. It is possible to enter and clear head / flow points at the bottom of the curve editor. Up to four curves for different speeds can be created, but they are rarely required as you will see.

Pump speed  
3,450 RPM Add... Delete



As you see on the left, the dotted line matches perfectly the 2350 RPM curve as it will for the 1560 and 750 RPM, so these are not required.


Clicking OK returns to the **Pump Curve Selection** dialog (Page 17). Once back, it is possible to **Add**, **Modify**, **Rename** and **Delete** pump curves by clicking the **Manage pumps curves ...** link.

The above advanced impeller settings are

used when the impeller is worn or not the original impeller or an adjustment to the flow results is required. The setting compensates for the impeller size, speed or calibration. These adjustments will only affect the system curve and not the pump curve loaded into the instrument.


For variable speed pumps, if a level and pressure sensors are connected to the Volucalc Hybrid CS, a manual adjustment of the Head allows adjustment of the flow calculated from the curves so it would match the real flow out of the pumps. A proper pump calibration might be needed to figure out the proper head adjustment.

Next step is to configure the alarms if they are needed on the Volucalc Hybrid CS. By default, based on the operation mode, the Volucalc Hybrid CS already have predefined alarms to detect standard problems. The view the predefined alarms or disable it, in the **Options...** menu, in the **Maid Configurator Tab**, check the **Predefined alarms** check box.



It's possible to create multiple type of alarms of different values. All the explanations are described in the Maid Device Configurator section in this manual.

The communication dialog is used to configure if the Volucalc Hybrid CS will be connected to the internet and how often the data is sent to the Maidmaps software. We recommend using the default values.



### *When configuration is ready*


Power up the Volucalc Hybrid CS and insert the USB drive to program the Volucalc Hybrid CS. If the Volucalc was already installed, we suggest to do a factory reset (Menu, Configuration, Technician, Factory Reset) before reinstalling the device to a new station. It's also recommended to back up the Mermaid files (USB, Mermaid) before.

1. You can connect all the connectors now.
2. Verify that the device is working properly
  - a. Check in the Real time windows (button 2) the current or rpm of each pump when ON and nothing when off.
  - b. If the level sensor is used, check that the value make sense
  - c. If pressure sensor is used, check that the value make sense
  - d. If MaidMaps SCADA Web Interface is used, do a Communication test in the menu (button 1).
  - e. After a moment or after a complete pump cycle check if the computed inflow make sense
3. Confirm that the installation of the Volucalc Hybrid CS doesn't affect the operation of the lift station.
4. Note all the information used to configure the device and if possible, take pictures of the general installation, of the connections and of the information at the lift station.
5. Before leaving, copy the Mermaid data from the USB menu (button 4), on the USB key in case of problem.



# VOLUCALC Hybrid CS MENU FLOWCHART

Level (ft):	17.72		
Next state in:	0:00:00		
Inflow(GPM)	0.00		
Outflow(GPM)	0.00		
1	111111	1	3
2	111111	2	4
MENU		RT	INFO
		USB	



Station										In			
Date	Energy Efficiency	Efficiency Lost	Wasted GWh	Use of Station	Maximum Level	Rain	Total Volume	Average Inflow	Flow	Minimum	Hour	Flow	Maximum
Unit:	G/Wh	kWh	kg	%	Ft	Inch	G	GPM	GPM	hh:mm:ss	hh:mm:ss	GPM	hh:mm:ss
1	1.53	64.04	N/A	31.14	6.86	0.11	804686	558.9	326.0	0:26:03	12:33:03	1265.8	12:33:03
2	1.56	102.48	N/A	30.63	6.76	0	778256	540.5	263.1	5:13:53	17:56:5	1776.5	0:12:55
3	1.54	88.76	N/A	29.41	6.73	0	744321	516.9	257.9	5:01:57	23:40:1	1515.37	0:15:37
4	1.53	64.52	N/A	37.49	6.99	0.24	936436	350.3	253.8	6:40:11	23:29.4	1515.32	0:13:03
5	1.59	87.42	N/A	37.02	6.86	0.19	N/A	N/A	N/A	N/A	N/A	N/A	N/A
6	1.60	218.22	N/A	33.93	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
21	1.5	1534.52	0	28.94	2.13	0.62	13278957	495.6	118.1	1/18/15 3:21	2808.0	1/5/15 0:13	N/A
Totals & Averages	1.5	1534.52	0	28.94	2.13	0.62	13278957	495.6	118.1	1/18/15 3:21	2808.0	1/5/15 0:13	N/A

Pump 1									
Date	Starts	Runtime including combinations	Runtime	Average Current	Volume	Efficiency	Capacity		
Unit:	hh:mm:ss	hh:mm:ss	A	G	G/Wh	GPM			
1	86	5:51:43	5:49:02	24.37	436184	1.71	1249.6		
2	86	5:46:18	5:43:00	23.88	436230	1.78	1271.8		
3	82	5:27:58	5:16:33	24.17	401661	1.75	1268.8		
4	73	6:50:24	6:27:52	24.7	491112	1.71	1266.1		
5	88	6:13:21	6:01:32	N/A	N/A	N/A	N/A		
6	85	6:03:04	N/A	N/A	N/A	N/A	N/A		
21	1482	94:08:05	93:04:47	24.59	7414164	1.80	1327.8		
Totals & Averages	1482	94:08:05	93:04:47	24.59	7414164	1.80	1327.8		

Pump 2									
Date	Starts	Runtime including combinations	Runtime	Average Current	Volume	Efficiency	Capacity		
Unit:	hh:mm:ss	hh:mm:ss	A	G	G/Wh	GPM			
1	86	5:53:53	5:51:12	24.03	442133	1.75	1259.0		
2	84	5:42:08	5:38:50	24.09	420459	1.72	1240.9		
3	81	5:41:20	5:29:55	23.99	407454	1.72	1235.1		
4	73	7:18:18	6:55:46	24.19	511529	1.70	1230.3		
5	86	6:56:02	6:44:13	N/A	N/A	N/A	N/A		
6	84	6:06:53	N/A	N/A	N/A	N/A	N/A		
21	1476	98:59:11	97:55:53	25.16	7517397	1.70	1279.9		
Totals & Averages	1476	98:59:11	97:55:53	25.16	7517397	1.70	1279.9		

Pumps 1 and 2									
Date	Starts	Runtime	Average Current	Volume	Efficiency	Capacity			
Unit:	hh:mm:ss	A	G	G/Wh	GPM				
1	1	0:02:41	43.71	0	0	0			
2	1	0:03:18	31.80	6190	1.97	1875.9			
3	1	0:11:25	32.97	21416	1.90	1875.9			
4	4	0:22:32	39.19	41555	1.57	1843.2			
5	1	0:11:49	43.22	N/A	N/A	N/A			
6	1	0:11:33	N/A	N/A	N/A	N/A			
21	9	1:03:18	33.74	416020.5	1.90	1816.7			
Totals & Averages	9	1:03:18	33.74	416020.5	1.90	1816.7			

Alarms And Suspicious Events									
Name	From	To	Duration	Threshold	Other Information				
Abnormal sequence	1/18/15 3:21	1/18/15 3:46	0:24:39	N/A	Multiple Pump 1 starts in a row				

## TCP/IP MODBUS TABLE




\* See IEEE 754

Address	Description	Type	Format	Scaling	Unit	Data min	Data max	Read/Write	Comments
40001	Current P1P1	Real Time	Unsigned Integer 16	10	Ampere	0	6535.5	Read	
40002	Current P2P1	Real Time	Unsigned Integer 16	10	Ampere	0	6535.5	Read	
40003	Current P3P1	Real Time	Unsigned Integer 16	10	Ampere	0	6535.5	Read	
40004	Current P4P1	Real Time	Unsigned Integer 16	10	Ampere	0	6535.5	Read	
40005	RPM P1	Real Time	Unsigned Integer 16	0	RPM	0	65535	Read	
40006	RPM P2	Real Time	Unsigned Integer 16	0	RPM	0	65535	Read	
40007	RPM P3	Real Time	Unsigned Integer 16	0	RPM	0	65535	Read	
40008	RPM P4	Real Time	Unsigned Integer 16	0	RPM	0	65535	Read	
40009	Starts P1	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40010	Starts P2	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40011	Starts P1-P2	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40012	Starts P3	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40013	Starts P1-P3	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40014	Starts P2-P3	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40015	Starts P1-P2-P3	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40016	Starts P4	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40017	Starts P1-P4	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40018	Starts P2-P4	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40019	Starts P3-P4	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40020	Starts P1-P2-P4	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40021	Starts P1-P3-P4	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40022	Starts P2-P3-P4	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40023	Starts P1-P2-P3-P4	Cumulative	Unsigned Integer 16	0		0	65535	Read	Rollover value
40024	Voltage external battery	Real Time	Unsigned Integer 16	10	Volt	0	6553.5	Read	
40025	Voltage	Fixed	Unsigned Integer 16	10	Volt	0	6553.5	Read	
40026	Power Factor	Fixed	Unsigned Integer 16	0	%	0	100	Read	
40027	Real Time Rain	Real Time	Unsigned Integer 16	100	mm/hour	0	6553.5	Read	
40028	Tap Water Pressure	Real Time	Unsigned Integer 16	0	kPa	0	65535	Read	
40029	Force Main Pressure	Real Time	Unsigned Integer 16	0	kPa	0	65535	Read	
40030	Level	Real Time	Signed Integer 16	100	Meters	-327.68	327.67	Read	
40031	Internal Temperature	Real Time	Signed Integer 16	10	Celsius	-3276.8	3276.7	Read	
40032	Head	Real Time	Signed Integer 16	100	m	-327.68	327.67	Read	
40034	Run Time P1	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40036	Run Time P2	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40038	Run Time P1-P2	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40040	Run Time P3	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40042	Run Time P1-P3	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40044	Run Time P2-P3	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40046	Run Time P1-P2-P3	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40048	Run Time P4	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40050	Run Time P1-P4	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40052	Run Time P2-P4	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40054	Run Time P3-P4	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40056	Run Time P1-P2-P4	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40058	Run Time P1-P3-P4	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40060	Run Time P2-P3-P4	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40062	Run Time P1-P2-P3-P4	Cumulative	Unsigned Integer 32	0	Seconds	0	4294967295	Read	Rollover value
40064	Serial Number	Fixed	Unsigned Integer 32	0		0	4294967295	Read	
40066	Delay before next event	Real Time	Unsigned Integer 32	0	Seconds	0	4294967295	Read	
40070	Capacity P1	Last used	Float 32	0	l/s	*	*	Read	
40072	Capacity P2	Last used	Float 32	0	l/s	*	*	Read	
40074	Capacity P1-P2	Last used	Float 32	0	l/s	*	*	Read	
40076	Capacity P3	Last used	Float 32	0	l/s	*	*	Read	
40078	Capacity P1-P3	Last used	Float 32	0	l/s	*	*	Read	
40080	Capacity P2-P3	Last used	Float 32	0	l/s	*	*	Read	
40082	Capacity P1-P2-P3	Last used	Float 32	0	l/s	*	*	Read	
40084	Capacity P4	Last used	Float 32	0	l/s	*	*	Read	
40086	Capacity P1-P4	Last used	Float 32	0	l/s	*	*	Read	

Address	Description	Type	Format	Scaling	Unit	Data min	Data max	Read/Write	Comments
40088	Capacity P2-P4	Last used	Float 32	0	l/s	*	*	Read	
40090	Capacity P3-P4	Last used	Float 32	0	l/s	*	*	Read	
40092	Capacity P1-P2-P4	Last used	Float 32	0	l/s	*	*	Read	
40094	Capacity P1-P3-P4	Last used	Float 32	0	l/s	*	*	Read	
40096	Capacity P2-P3-P4	Last used	Float 32	0	l/s	*	*	Read	
40098	Capacity P1-P2-P3-P4	Last used	Float 32	0	l/s	*	*	Read	
40100	Inflow	Real Time	Float 32	0	l/s	*	*	Read	
40102	Outflow	Real Time	Float 32	0	l/s	*	*	Read	
40104	Open Channel Flow	Real Time	Float 32	0	l/s	*	*	Read	
106/0	Relay P1	Real Time	Coil	-	-	0-1		Read	
106/1	Relay P2	Real Time	Coil	-	-	0-1		Read	
106/10	Pump status 3	Real Time	Coil	-	-	0-1		Read	
106/11	Pump status 4	Real Time	Coil	-	-	0-1		Read	
106/2	Relay P3	Real Time	Coil	-	-	0-1		Read	
106/3	Relay P4	Real Time	Coil	-	-	0-1		Read	
106/4	Relay Out 1	Real Time	Coil	-	-	0-1		Read	
106/5	Relay out 2	Real Time	Coil	-	-	0-1		Read	
106/6	Digital Input	Real Time	Coil	-	-	0-1		Read	
106/7	12v output	Real Time	Coil	-	-	0-1		Read	
106/8	Pump status 1	Real Time	Coil	-	-	0-1		Read	
106/9	Pump status 2	Real Time	Coil	-	-	0-1		Read	
	Total Rain	Cumulative	Unsigned Integer 16	0	mm	0	65535	Read	Available soon
	% of use of the station	Real Time	Unsigned Integer 16		%	0	100	Read	Available soon
	Efficiency P1	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P2	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P1-P2	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P3	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P1-P3	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P2-P3	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P1-P2-P3	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P4	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P1-P4	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P2-P4	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P3-P4	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P1-P2-P4	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P1-P3-P4	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P2-P3-P4	Last used	Float 32	l/kWh		*	*	Read	Available soon
	Efficiency P1-P2-P3-P4	Last used	Float 32	l/s		*	*	Read	Available soon
	Total Volume In	Cumulative						Read	Available soon
	Total Volume Out	Cumulative						Read	Available soon
	Alarm 1							Read	Available soon
	Alarm 2							Read	Available soon
	Alarm 3							Read	Available soon
	Alarm 4							Read	Available soon
	Alarm 5							Read	Available soon
	Alarm 6							Read	Available soon
	Alarm 7							Read	Available soon
	Alarm 8							Read	Available soon
	Alarm 9							Read	Available soon
	Alarm 10							Read	Available soon
	Alarm 11							Read	Available soon
	Alarm 12							Read	Available soon
	Alarm 13							Read	Available soon
	Alarm 14							Read	Available soon
	Alarm 15							Read	Available soon
	Alarm 16							Read	Available soon
	Alarm 17							Read	Available soon
	Alarm 18							Read	Available soon
	Alarm 19							Read	Available soon
	Alarm 20							Read	Available soon

Physical Specifications	
Physical Size in inches (cm)	5.7 x 3.9 x 2.14 (14.5) x (9.9) x (5.5)
Weight	0.5 lb/0.22 kg
Working temperature	-4° to 140° F (-20° to 60° C)
Storage temperature	-22° to 158° F (-30° to 70° C)
Display	Backlit graphic monochrome 3" 128 x 64 pixels LCD.
Power Specification	
12 VDC Input	10 to 26 VDC, 2A max.
Battery input	16v max. Integrated 12 VDC lead acid battery charger. Do not connect a non-rechargeable battery.
P1 to P4 pumps inputs	1.5 VAC or 4-20 mA, 0-5 VDC, 0-10 VDC, 0-24 VDC ±0.1% precision. 40 measurements per second.
P1 to P4 Relay outputs, Relay 1 out and Relay 2 out	Dry contact relay, 24 VDC max. 1A resettable fuse protected (PTC). 1hz output max.
Level Input and Pressure Input	4-20 mA, 0-5 VDC, 0-10 VDC, 0-24 VDC ±0.1% precision. 40 reads averaged each second.
Flow 4-20 mA output	Self-powered 4-20 mA output, 600ohms load max. Updated every second.
12VDC output	(12VDC Input voltage or battery input voltage) minus 1.5 VDC. 1A max. Controlled by the device. Resettable fuse protected (PTC).
Digital Input	Self-powered dry contact input. 3.3 VDC. 100uA min. Can accept 5v signal max. 10hz max.
Other connectors	
Ethernet connector	RJ45 connector with 10BaseT network capabilities
USB	Standard USB-A port to read/write FAT or FAT32 formatted USB drive. Max 100mA.
Other	
Internal memory	2 gigabytes. Enough memory for the entire life of the product without erasing it. Automatically cleaned when device need more memory. Can be formatted on demand.
Accuracy	
Volumetric flow accuracy (normal operation)	± 1.5 % for most lift station with inlet above pump operating levels. It allows calculating flow with a partially submerged inlet.
Open channel flow accuracy	Based on level sensor specifications and flow equation used. Available formulas: Manning, California pipe, Rectangular weir with end contractions, Rectangular weir without end contractions, V-notch (or triangular) weir and Trapezoidal (or Cipolletti) weir or use a standard or polynomial flow formula or a lookup table.
Real time clock accuracy	Max 10 seconds per month. Auto correction if the device has internet access.
Internal temperature sensor accuracy	±3°C
Warranty	
Volucalc Hybrid CS	3 years, part and labor.

## Dimensions



Height 5.5 cm (2.2 in), Length 14.5 cm (5.7 in) , Width (including connectors and wires) 11 cm (4.33 in)

When installing, provide enough space above the instrument for the Ethernet port (2 cm 0.8 in) if used, and below the instrument for the connector and wires (1.5 cm 0.6 in).

Communication

Devices communicate with a web server via a continuous internet connection. There is no configuration required when connecting to Maid Labs. The devices use port 80 (standard port for all web pages) to communicate with the MaidMaps server. If a computer in the network is capable of browsing the internet, then the communication will work.

Devices are DHCP clients and require no special configuration with the exception of having a DHCP server in the network (present in all standard networks). It is not possible at the moment to enter a fixed IP address to a device. It is possible to connect the unit to a Wi-Fi connection using an external module sold by Maid Labs. Configuration of the module is required using a computer. To know the IP address of the device or its MAC address, from the main screen, press the MENU 1 key, then 3 twice and ENTER 4 to display IP Informations. The screen provides the communications and network information including IP, MAC address, network Mask and Gateway data.

Screens

Main Screen

Level (ft):		17.72	0:00:00
Level (ft):	17.72		
Head (ft):	1.97	0.00	
Pressure(GPM)	0.00	0.00	
Outflow(GPM)	0.00	3	07/03
1	3	07/03	4 14:35
2	4	14:32	FO   USB
MENU   RT   INFO   USB			

The main screen of the VOLUCALC™ Hybrid CS is different for constant speed (front) and variable speed (back) pumps. It displays some computed data, sensor

readings and the contextual use of the 4 keys of the keyboard. The 4 menu screens on the right are related to the 4 keys as displayed on the bottom row of the main screen.

Level (ft) 0.00 The level is displayed according to the configuration chosen by the user.

Next state in: 0:00:00 Displays approximatively time to wait until a pump starts or stops.


Inflow (GPM) 0.00 Displays flow coming in the station as calculated by the selected algorithm.

Outflow (GPM) 0.00 Displays flow pumped out of the station as calculated by the selected algorithm.

Head (ft) 0.00 Displays head calculated or entered.

Pressure (PSI) 0.00 Displays pressure read by the sensor or entered.

- This symbol indicates that there is no "Ethernet" connection.
- This symbol indicates there is an « Ethernet » connection. The Ethernet cable is connected and the IP address is valid (communication is not necessarily functional).



⏏ This symbol indicates that the internal relay contact is open or ⏏ close. The group of 4 represents the 4 pump outputs and the group of 2 represents the 2 relays of the bottom connector of the Volucalc Hybrid CS.


**1** When dark, it indicates the pump is in operation.

02/07 11:35 The current date and time is displayed.

## Numbers selection screen

The setting for the Volucalc Hybrid CS is easier using the *Maid Devices Configurator* software (on page 13 and 41). However, it is possible to set many functions from the display screen.

A scrolling scale 0 to 9 allows to select a value which is boxed **5**. Scroll using the **←** **2** and **→** **3** buttons. To select a number, press **ENTER** **4**



..

**←** is to correct or erase a number.

**→** is to accept the number and exit the menu.

When the curser comes on at **+**, press **4** and change to a negative number.

A negative value may be necessary for some parameters in the overflow equations. It is important to note that in some cases, the entered number will be validated. In such a case, an error message might appear below the window. The user will also be limited as to the number of digits after the decimal.

## MENU **1**

Pressing the **MENU** **1** button displays 8 options. Browse the menu with the **←** **2** **→** **3** keys, and press **ENTER** to execute.

1. Configure the device
2. Displays data relative to the hardware and software
3. Display IP addresses and network information.
4. Test the communication with Maidmaps.
5. Test the relay
6. Test the analog output
7. Lock the screen
8. Stop or reboot the device.

## Configuration Menu

From the main screen, press the **MENU** **1** key to access the menu, and then **ENTER** **4** to open the Configuration menu. This enables to configure the following settings. Scroll through the menu with the **←** **2** and **→** **3** keys, and then press **ENTER** **4** to execute.

- |                     |                                      |
|---------------------|--------------------------------------|
| 1. Date & Time      | 6. Channel flow setup                |
| 2. Units            | 7. Bandwidth setup                   |
| 3. Display          | 8. Alarms setup                      |
| 4. Inputs / Outputs | 9. Download Settings (Configuration) |
| 5. Level setup      | 10. Firmware Upgrade                 |



- |   |                     |
|---|---------------------|
| 11. Language                                  | 15. Pump Capacities |
| 12. Lock Screen Password                      | 16. Pump Ratio      |
| 13. Pressure Override (if no pressure sensor) | 17. Report Options  |
| 14. Level Override (if no level sensor)       | 18. Technician      |

After a function is completed, press **RETURN** **[1]** to return to the previous menu. The list of submenus is longer than what is displayed on the initial screen.

## Date & Time setup

In the **Configuration** (above) menu, press **▼** **[3]** to **Date & Time**, then press **ENTER** **[4]** to execute this function.

This menu displays time, date, and the difference to the Universal Time Coordinated (UTC), also known as Greenwich Mean Time (GMT). With a working Internet connection, the instrument updates automatically its internal clock using internet time. It is possible to force the update via internet with the button **SET** **[3]**.

When the **Bandwidth** (page 30) is disabled, time modification is possible with these keys **-**, **+** and **NEXT**. A cursor appears under the first number that can be changed. Keys **▲** **[2]** and **▼** **[3]** are to change the value and **NEXT** **[4]** is to go to the next variable.

The data is stored in Greenwich Mean Time – GMT and then adjusted to local time for display and when generating files and reports. This prevents the loss of data caused by changes to daylight savings time to standard time and vice versa. Changes to the time or date can cause loss of data when entering an older time or date. If this happens, the data following the entered time and date are lost. In this case, a warning message will appear. Changing the GMT relation does not cause a loss of data.

## Units

In the **Configuration** (page 28) menu, press **▼** to **Units**, then press **ENTER** **[4]** to select. The units can be chosen based on settings. Press the **EDIT** **[4]** key to move from one unit to another and the **▲** **[2]** keys and **▼** **[3]** to move from one parameter to another.

## Display

In the **Configuration** (page 28) menu, press **▼** **[3]** to **Display**, and then press **ENTER** **[4]** to select.

Press **ENTER** **[4]** to select the **Brightness** setting, then **▲** **[2]** or **▼** **[3]** to adjust it between 0% (off) and 100%, in increments of 20%, then **ENTER** **[4]** again to accept it.

The backlight (brightness) and display can be disabled by adjusting the on-time in these features. Press **ENTER** **[4]** to accept the selection, then **▲** **[2]** and **▼** **[3]** to change, then **ENTER** **[4]** again to accept the selected time.

## Inputs/Outputs

In the **Configuration** (page 28) menu, press **▼** **[3]** to **Inputs/Outputs**, then press **ENTER** **[4]** to select. VOLUCALC™ Hybrid CS has several entries of various types that can be configured:

- |                   |                  |
|-------------------|------------------|
| 1. Analog Out     | 4. Relay Out 1   |
| 2. Level Input    | 5. Relay Out 2   |
| 3. Pressure Input | 6. Digital Input |

The configuration through the screens is intuitive, but it is wiser to use the MAID Device Configurator to do it.



## Level setup

In the **Configuration** (page 28) menu, press **3** to **Level Setup**, then press **ENTER 4** to select. The level configuration is used to adjust the values read by the device with the actual measured values. The only parameter to be set is the thickness of water currently read by the sensor. Simply press the **MODIF 4** key. If there is no water to measure, enter 0. The device will automatically adjust its settings. It is possible to reset all the settings by using the **RESET** key.

## Channel Flow (Overflow) Setup

In the **Configuration** (page 28) menu, press **3** to **Channel Flow Setup**, then press **ENTER 4** to select. Two options: **Flowmeter** or **Overflow**.

To record digital overflow with a dry contact, a device like a float switch needs to be connected to the **RAIN IN pH** input. It must be configured as a digital input and is only used to record the number of times a set level is reached and duration of these events.

In **Overflow** mode, a level sensor is connected to the **LEVEL IN** input of the device. It can be configured as an open channel flow meter, while still able to monitor the levels, record the duration and event while in an overflow condition. In **Overflow** mode, the **Level (ft)** is measured in real time, and the **Compute flow over** is the level at which the overflow began and open channel flow starts recording. This is the only value that the user can define. To do this, press the **EDIT** key using the *Numbers selection screen* (page 27), then accept the value with the **APPLY** key.

In **Flowmeter** mode, the device simply always record and compute the flow over 0. The device don't store the events as separate events in **Overflow** mode but all the events are totalized for each day. Press **APPLY 4** key to continue. An open channel flow equations window appears.

## Open Channel Flow Equations (Overflow)

Depending on the type of weir or primary device used, you can select among the 13 equations listed on page 46. The set engineering units are displayed in the parameter input screen. When multiple parameters are required, press **OK 4** to move on. To select an item in a list, press **LIST** and to change a value, press **EDIT** and follow the instructions on page 31. The keys may have different functions depending on the selected equation.

## Bandwidth setup

In the **Configuration** (page 28) menu, press **3** to **Bandwith setup**, then press **ENTER 4** to select. The bandwidth setup screen allows changing four parameters for communication with the MaidMaps web server.

The first parameter determines whether or not to activate the communication with the MaidMaps server. The second indicates the delay between events uploaded to MaidMaps. These data allows displaying sensor values on the map and generating graphs from the web interface. The third parameter defines the delay between dayt files uploaded to MaidMaps. This applies to both .csv reports generated by the instrument and technicians files allowing a detailed monitoring of the operation of the device. The last parameter allows, when an overflow or an alarm configured accordingly, immediate transmission of data when it is running on battery.

## Alarms setup

In the **Configuration** (page 28) menu, press **3** to **Alarms setup**, then press **ENTER 4** to select.

**WARNING! Sending alarms to MaidMaps is not fully integrated. Until it is completed, alarms must be created in the device and in MaidMaps . If no alarm is configured on the device, when operating on battery, the device will not wake up to transfer its information to MaidMaps, so no real-time alarm will be issued.**

Alarms setup in the device allows to be notified on the screen, using a relay contact or an internet connection is present, the web application MaidMaps when a predetermined condition occurs. You can configure alarms on several types of readings and conditions. The choices are to add an alarm, edit existing alarms, delete an existing alarm, cancel current changes to alarm or restore the default alarms present in the initial configuration. When **Add** or **Modify** is selected, a window with the options of this alarm is displayed:

The **Add** option allows enabling or disabling an alarm without having to delete it. **Data** is used to determine for what type of data this alarm is present. **Type** lets you choose whether the alarm is active if the reading exceeds **High** or **Low** when under the threshold. **Interval** is a third choice, which allows generating an alarm when the value is in the specific interval. The **threshold** is the value at which an alarm is generated.

The **Threshold2** can be setup only when the **Type** field is on **Interval**. The next parameter is **Delay before beginning** which specifies for how long the state should be valid before an alarm is considered active. **Delays after end** also allows you to filter alarms and wait for a predetermined time when the state is no longer valid before considering the alarm as complete. Thereafter, the **Display** option advises you on screen when an alarm becomes active. **Must recognize** requires an acknowledgment from the user so the alarm shuts down.

**Send to MaidMaps** allows, where internet communication is available, to transmit the list of alarms transferred to the MaidMaps web application. The options **Initial** delay and **Final** delay allows to be informed via the MaidMaps web application by SMS, email or otherwise when the alarm starts or ends. When the **Relay Active** settings are at **YES**, for a relay output **Relay Out 1** for example, in the list of inputs and outputs, is set in alarm mode, then the relay contact will close when the alarm will be considered active.

## Download settings

In the **Configuration** (page 28) menu, press **▼** **3** to **Download settings**, then press **ENTER** **4** to select. This is to read the configuration file and to copy the firmware.

## Reset total events

In the **Configuration** (page 28) menu, press **▼** **3** to **Reset total events**, then press **ENTER** **4** to select. This function resets the total events contained in the main screen. After selecting this function, press **YES** **3** to confirm the deletion of the data from the main screen or **CANCEL** **1** to return to the previous screen.

To reset the Volucalc Hybrid CS “as new”, go to the **Factory Reset** function (page 32). A configuration file on a USB drive must be available to restart the Volucalc Hybrid CS since it has no configuration following a factory reset.

## Firmware Upgrade

In the **Configuration** (page 28) menu, press **▼** **3** to **Firmware upgrade**, then press **ENTER** **4** to select. Be sure of the reliability of the energy source before beginning the programming of the instrument. There must not be any power loss during the update. After selecting **Firmware update**, insert a USB drive that contains the **volucalcrt.hex** file in the root directory. Once this file is detected, the update programming will automatically start and a percentage of the update progress will be displayed in steps. The instrument restarts when the update is completed. This does not affect the configuration of the Volucalc Hybrid CS.

## Language

In the **Configuration** (page 28) menu, press **▼ 3** to **Language**, then press **ENTER 4** to select. The instrument can work in French or English. Press **▼ 2** or **▲ 3** to select the language, then **APPLY 4** to accept the displayed language.

## Lock screen password

In the **Configuration** (page 28) menu, press **▼ 3** to **Lock Screen Password**, then press **ENTER 4** to select. By default and if no lock has been configured, simply press 1234 to have full access to the menus of the device. To create a custom locking key, press **EDIT 3** and enter a 5-digit code between 1 and 4, using the keys **1**, **2**, **3** and **4**.

## Pressure Override and Level Override

In the **Configuration** (page 28) menu, press **▼ 3** to **Pressure Override** or **Level Override**, then press **ENTER 4** to select.

The override selection for pressure and level allows the user to input a value for damaged or missing sensors. Please note, these values will not change and will affect the accuracy of the data.

Press the **ON 3** key to indicate that a pressure or level will be entered, then **EDIT 2**, follow the instructions at page 31, then press **APPLY 4** to accept the value. To deactivate the fixed pressure or level, press **OFF 3**.

## Pump Capacities

In the **Configuration** (page 28) menu, press **▼ 3** to **PUMP Capacities**, then press **ENTER 4** to select. If pump capacities are used to calculate a derived flow, the values entered in the MAID Device Configurator are displayed.

## Pump Ratio

In the **Configuration** (page 28) menu, press **▼ 3** to **PUMP Ratio**, then press **ENTER 4** to select. If pump capacities are used to calculate a derived flow and a ratio is used to calculate capacities for combinations of pumps, then the ratio used will be displayed.

## Report Options

In the **Configuration** (page 28) menu, press **▼ 3** to **Report Options**, then press **ENTER 4** to select. This option is to filter events that are too short to be significant in the digital reports (mainly for overflow measurement with a float). If events are shorter than the set time, no event will be recorded. If multiple events occurs during the set time, only one event will be recorded.

## Technician

In the **Configuration** (page 28) menu, press **▼ 3** to **Technician**, then press **ENTER 4** to select. The technician menu allows access to functions that are normally reserved for factory or experienced technicians. In this menu, please note there are functions that could totally erase the memory of the instrument. These are the functions of **Technician** :

- |                       |                         |
|-----------------------|-------------------------|
| 1. Factory Reset      | 2. Erase Files          |
| 3. SD Card Info       | 4. Copy Manual from USB |
| 5. Copy App from USB  | 6. ScreenShot           |
| 7. Inputs Calibration | 8. Raw Values           |

## Factory Reset

This resets the device to the same condition that it was when new and never installed. To start press (in the order) **3** and **2**. Nothing will be in the internal memory after this execution. It is equivalent to formatting the disk of a computer. **A configuration file on a USB drive must be available to restart the Volucalc Hybrid CS since it has no configuration following a factory reset.**

## Delete File

This function allows the user a selection of files to be deleted from the memory. Only do that if a Maidlabs technician ask you to.

To delete a selected file, press **ENTER 4**, then **OK 2** to confirm.

## SD Card Info

This function allows you to check the amount of memory for internal memory and free space. With 2 GB or more of memory, there is enough memory for the lifetime of the instrument, or more than 10 years.

## Device info

From the main screen, press the **MENU 1** key, then **➔ 3** one time and **ENTER 4** to display **Device Info**. Displays the serial number of the instrument. The serial number is required to create a configuration file .

## IP Information

From the main screen, press the **MENU 1** key, then **➔ 3** twice and **ENTER 4** to display **IP Informations**. This screen provides the communications and network information including IP, MAC address, network Mask and Gateway data.

## Communication test

From the main screen, press **MENU 1** to enter the menu, then the arrow **3** and **ENTER 4** to initiate the communication test. The **TEST 4** key allows to manually repeat the test to observe the commands that are sent. The button **Init. 3** is used to reinitialise the connexion with Maidmaps and resend all new data immediately. **Communication Test** screen indicates if a network cable is connected to the device, if its IP address is valid or not and its IP address. On the screen, under the IP address, the text **Successful Communication** and **Communication Failed** will appear after the communication test. The test may take a few seconds to execute.

**Successful Comm.**  
**26/09 10 :10. 4. 0**

Information appearing under the “Successful Communication” status is the date and time of the last communication, the command sent (represented by a digit) and the replies received. This information is not important to the user but allowed the technician to better diagnose a problem.

## Relay test

From the main screen, press the **MENU 1** key, then **➔ 3** 4 times and **ENTER 4** to do a **Relay test**. The user can change the status of the internal relay contacts of the instrument.

⏏ This symbol indicates that the internal relay contacts are open.

⏏ This symbol indicates that the internal relay contacts are closed.

Press **3** to open the relay and **4** to close it. You should be able to hear it change positions.

## Analog output test

From the main screen, press the **MENU** **1** key, then **⏏** **3** 5 times and **ENTER** **4** to **Analog Out Test**. The user can change the value of the 4 to 20 mA analog output in 1 mA increments by pressing the buttons **-** **2** to decrease the value and **+** **3** to increase it.

## Lock screen

From the main screen, press the **MENU** **1** key, then **⏏** **3** 6 times and **ENTER** **4** to execute **Lock Screen**. Lock screen allows restricting access to the device in the main menu. By default, if no lock key has been configured, simply press **1**, **2**, **3**, **4** to have full access to the menus of the unit. If the lock key has been configured (*lock screen password*, page 31), just grab it with the buttons. The device automatically locks the screen after 30 seconds.

## Shutdown or reboot device

From the main screen, press the **MENU** **1** key, then **⏏** **3** 7 times and **ENTER** **4** to open the screen. Press button **3** to **Shutdown device** or button **2** to reboot. This procedure is recommended when there is maintenance to do on the device, for example, a battery change. This avoids the possibility of losing recent data that has not been stored. This function stops all operations of the device. To restart normal operations, simply remove the power including the batteries and reconnect after a few seconds.

## RT **2** (Real Time)

From the main screen, press the **RT** **2** key to display the Real Time screen.

The RT menu displays information in real time.



### Real time

From the main screen, press the **RT** **2** key, then **ENTER** **4** to display the **Realtime** screen.

**Lvl** **0.0** level represents the current data from the probe.

**Head** **0.0** is the current head pressure, a difference between the inlet or level pressure and the pumped outlet pressure.

**Press.** **0.0** represents the pressure at the pump outlet.

**Flow** **0.0** represents the flow rate calculated using the derived flow algorithm.

**P1** to **P4** represents the pump inputs.

**RPM** indicates a rotation speed in Revolution Per Minute.

Realtime			
Lvl	0.0	Press.	0.0
Head	0.0	Flow	331.3
P1	P2	P3	P4
RPM	RPM	A	GPM
0.0	0.0	0.0	0.0
BACK			

P1	P2	P3	P4
RPM	RPM	A	GPM
0.0	0.0	0.0	0.0

A indicates a current in Amp.

GPM, l/s or other flow unit will be displayed if an external flow meter is connected to the VOLUCALC™ Hybrid CS and it is recording the displayed flow.

If nothing is connected, then N/A (non available) will be displayed.

### Pump Statistics

From the main screen, press the RT [2] key, then [3] and ENTER [4] to display **Pump Statistics** of the first pump. This screen provides statistics for each pump (not pump inlet) accumulated since the last time the cumulative statistics were cleared (see page **Erreur ! Signet non défini.**) or a "Factory Reset" (page 35) was executed. Information includes:

1. **Starts** - Number of starts
2. **Run time**
3. **Avg. Outflow** - Average flow out of the pumps
4. **Total vol.** - Total pumped volume
5. **Curr. Outflow** - Current Outflow

The keys [2] and [3] are used to scroll from one pump to another.

Pump Statistics 1	
Starts	32
Runtime	20:57:52
Avg. Outflow	0.0
Total Vol.	1576222.1
Curr. Outflow	0.0
BACK   +   -	

Pump Statistics 2	
Starts	100
Runtime	33:07:30
Avg. Outflow	20.9
Total Vol.	7028282.0
Curr. Outflow	20.9
BACK   +   -	

### Power Consumption

From the main screen, press the RT [2] key, then [3] twice and ENTER [4] to display **Power Consumption**. This screen displays the overall power consumption and kilowatt hour per pump. To achieve this, VOLUCALC™ Hybrid CS multiplied the current from the sensor by the number of phase by the voltage and the factor power. (Page 14 and 44)

Power Consumption	
Total:	0.0 kWh
Pump1:	0.0 kWh
Pump2:	0.0 kWh
BACK   \$   \$/kWh   Reset	

BACK [1] is to get to the previous menu

\$ [2] will switch between kWh and \$. \$ is the cost of operating the station and the pumps.

\$/kWh [3] will change the cost per kWh

Reset [4] will reset the kWh values to zero (0).

### Internal Info

From the main screen, press the RT [2] key, then [3] 3 times and ENTER [4] to display **Internal Info**.

If batteries are installed in the instrument (depending on the model version), this screen allows you to see the voltage capacity.

The temperature displayed is accurate to  $\pm 3^{\circ}$ .


12VDC:	ON
External battery:	0.00V
Charging:	OFF
Digital Input:	Inactive
Analog input:	0.00m
Level input:	0.00PSI
Internal temp.:	28.5 C
BACK	

### Rain Statistics

From the main screen, press the RT [2] key, then [3] 4 times and ENTER [4] to display the **Rain Stats.**

Rain Stats.	
Total:	0.0 mm
This Month:	0.0 mm
Rain today:	0.0 mm
BACK       Reset	






## INFO




From the main screen, press the **INFO**  key.

Four reports are available:

- **Events Reports** displays events relative to the digital input,
- **Alarms Report** displays alarms recorded by the device
- **Channel Flow Report** displays daily flow, or overflow and S.S.O. depending on the configuration of the device.
- **Volucalc Report** displays generic information about the station like daily flow, runtime, starts, power consumptions.

Press **ENTER**  to execute.

The current month is automatically preselected. Press **MONTH**  or **YEAR**  to select the month or year to change, and then   to scroll among the months and years for which data was recorded, and press **ENTER** .



Once the month has been selected, recorded daily information for that month can be viewed. To view daily details select the day to view the recorded events using  , and then press **ENTER**  to display it.

The daily detailed report displays the date in the format **MM/DD** and time in the format **HH:MM**. On each line, there is the start time of the event,

followed by its duration. Note that a duration of **00:00** means that it lasted less than 60 seconds. In the

overflow report, the **Flow** will also be displayed. When pressing the **NEXT**

 button, the last column displays the **Volume**.

If a day is not selected, the first event of the month will be displayed, then the next etc... In any case, press   to scroll through all events within the selected month.

Alarms	Qty	Dur.
MM/DD/YY		HH:MM
07/01/13	0	00:00
07/02/13	0	00:00
07/03/13	0	00:00
07/04/13	0	00:00

Start	Dur.	Type
MM/DD HH:MM	HH:MM	
03/14 15:46	00:00	???

Events	Qty	Dur.
MM/DD/YY		HH:MM
07/01/13	0	00:00
07/02/13	0	00:00




  

Events	Start	Dur.
MM/DD/YY	HH:MM	HH:MM:SS
03/14/13	15:47	00:00:00

## USB

From the main screen, press the **USB**  key. This menu is to:

1. Copy reports on the USB key
2. Copy this instrument manual to USB key
3. Copy MerMaid format data the USB key
4. Copy to the USB key data that would allow the technician to help out, if necessary.

Press   to select the function to execute, then **ENTER** .

Use a USB drive formatted with FAT16 or FAT32. The amount of files on the key influence the time to copy files. It is best to reserve the use of a USB key downloads from MAID Labs' instruments.

USB
Reports
Copy User Manual
MerMaid Data
Technician Data



Insert a USB drive when a message asks for it. When the transfer is completed, a message indicates that you can remove the key.

## Reports

While viewing main screen, press the **USB** **4** key, then **ENTRER** **4** to access the **Reports** menu. The 3 choices are:

1. **Monthly Events**, (per the next page) without the volumes and average flow.
2. **Monthly Overflow**, which has flow and volume data
3. **Monthly Volucalc**, which summarize the monthly operation of the station.

The monthly reports are in CSV format. If Excel™ is installed on the computer, monthly reports will load automatically. The file name is composed of an identifier (name or serial number) plus the year and the month for which it is created. Note: If the device language is different from your computer, the data might not be presented properly in Excel. To remedy this, simply select the appropriate separator when importing into the spreadsheet (Excel).

A file is created for each month of operation of the instrument, unless all the data has been deleted intentionally using the Technician menu on page 27

Examples of reports are on the two next pages, the text format was altered to make them easier to read.

The reports are copied on the USB key in the subdirectory Monthly Reports, which is under the directory with the name given to the instrument or having its serial number in the root directory. See Device Name on page 37.

The **Monthly Events** report summarize the monthly information regarding events recorded through the instrument's digital input, or which occurred because a set point was reached. This report looks like this one, without the two right columns.

The **Monthly Overflow** report summarize the monthly information regarding events recorded through the instrument's digital input, or related to a reached set point. When the set point is reached, Volucalc Hybrid CS uses the selected open channel equation to evaluate the quantity of water lost during the events and the average flow of these events.

If the set point is placed very low, then this report can be used as a monthly report showing the total quantity of water going through the station.

Site: LS 24	12-2012	Overflow	Volume	Avg Flow	Date	From	To	Duration	Volume	Avg Flow
Date	Duration	Qty	Gallons	GPM	7	07:45:03	07:45:18	00:00:15	2.0	8.00
1	N/A	N/A	N/A	N/A	8	10:21:23	12:22:22	02:00:59	2,548.0	21.06
2	N/A	N/A	N/A	N/A	8	13:03:25	14:23:25	01:20:00	32,811.0	410.14
3	N/A	N/A	N/A	N/A	8	15:02:01	15:35:13	00:33:12	11,453.0	344.97
4	N/A	N/A	N/A	N/A	9	14:31:14	16:31:35	02:00:21	80,749.0	670.95
5	N/A	N/A	N/A	N/A	9	15:00:23	15:00:36	00:00:13	21.0	420.00
6	N/A	N/A	N/A	N/A	10	09:12:11	09:12:16	00:00:05	0.1	1.44
7	0:00	1	2	8.00	10	09:41:04	09:41:14	00:00:10	1.0	6.00
8	3:54	3	46,812	3.33	11	10:01:16	11:15:25	01:14:09	29,027.0	391.46
9	2:21	2	80,770	11.17	12	10:25:49	10:26:51	00:01:02	4.2	126.00
10	0:00	2	1	0.07	13	10:15:00	10:15:15	00:00:15	2.1	8.40
11	1:14	1	29,027	391.46	14	09:31:59	09:32:05	00:00:06	0.9	9.00
12	0:00	1	4	126.00	14	09:32:10	09:32:15	00:00:05	0.8	9.60
13	0:00	1	2	8.40	15	14:21:15	14:21:44	00:00:29	5.0	10.34
14	0:00	2	2	0.15	16	02:55:01	07:05:46	04:10:45	46,871.0	186.92
15	0:00	1	5	10.34						
16	4:10	1	46,871	186.92						

If the VOLUCALC™ Hybrid CS was not installed on the first day of the month N/A (Not Available) appears on the lines on these dates without data.

Following the daily data begins the details of each event.

The **Monthly Volucalc** report summarize the

station's data. This report is an html report. It can be displayed in any browser. Simply double click on the file and the default browser on your computer will open the file. It provides the date of the report, the station and the month of the recorded data. The Average Outflow is the average flow rate based on the pump curves, the pump capacities, or the external flow



meter connected to an analog input. Same with the volumes. For the open channel equation, use the Monthly Overflow report of the previous page. For variable speed pumps, the runtime is usually high and the number of starts low. Constant speed pumps are opposite.

## Copy User Manual



From the main screen, press the **USB** **4** key, then **+** **3** and then **ENTER** **4** to access **Copy User Manual**. This function copies the PDF version of this user manual from the internal memory of the instrument to a USB key.

## MerMaid / Tech Data

From the main screen, press the **USB** **4** key, then **+** **3** twice and then **ENTER** **4** for **MerMaid Data**. The data is copied into a file that is formatted for the MerMaid software. To learn more about how to use the data of the MerMaid format, visit [www.maidlabs.com/software-mermaid/](http://www.maidlabs.com/software-mermaid/).

## Copy config to USB

This function is used to export the configuration of the Volucalc Hybrid CS to the USB key so the file can be opened with the Maid Device Configurator. It's also possible to export the configuration of the device with Mermaid software through the Mermaid Data file (.mldata).

Date	Station						In					
	Energy Efficiency	Efficiency Lost	Wasted GHG	Use of Station	Maximum Level	Rain	Total Volume	Average Inflow	Minimum		Maximum	
	Unit:	G/Wh	kWh	kg	%	Ft	Inch	G	GPM	GPM	hh:mm:ss	hh:mm:ss
1	1.53	64.04	N/A	31.14	6.86	0.11	804686	558.9	326.0	0:26:03	1265.8	12:33:03
2	1.56	102.48	N/A	30.63	6.76	0	778256	540.5	263.1	5:13:53	1776.5	0:12:55
3	1.54	88.76	N/A	29.41	6.73	0	744321	516.9	257.9	5:01:57	2340.1	0:15:37
4	1.53	64.52	N/A	37.49	6.99	0.24	936436	350.3	253.8	6:40:11	2329.4	0:15:32
5	1.59	87.42	N/A	37.02	6.86	0.19	811151	341.1	248.0	6:08:00	2289.0	0:13:03
6	1.60	218.22	N/A	33.97	6.86	0.19	811151	341.1	248.0	6:08:00	2289.0	0:13:03
7	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
8	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Totals & Averages	1.5	1534.52	0	28.94	2.13	0.62	13278957	495.6	118.1	1/18/15 3:21	2808.0	1/5/15 0:13

Pump 1							
Date	Starts	Runtime including combinations	Runtime	Average Current	Volume	Efficiency	Capacity
Unit:		hh:mm:ss	hh:mm:ss	A	G	G/Wh	GPM
1	86	5:51:43	5:49:02	24.37	436184	1.71	1249.6
2	86	5:46:18	5:43:00	23.88	436230	1.78	1271.8
3	82	5:27:58	5:16:33	24.17	401661	1.75	1268.8
4	73	6:50:24	6:27:52	24.7	491112	1.71	1266.1
5	88	6:13:21	6:01:32	24.7	491112	1.71	1266.1
6	85	6:03:04	5:51:12	24.03	442133	1.75	1259.0
7	N/A	N/A	N/A	N/A	N/A	N/A	N/A
8	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Totals & Averages	1482	94:08:05	93:04:47	24.59	7414164	1.80	1327.8

Pump 2							
Date	Starts	Runtime including combinations	Runtime	Average Current	Volume	Efficiency	Capacity
Unit:		hh:mm:ss	hh:mm:ss	A	G	G/Wh	GPM
1	86	5:53:53	5:51:12	24.03	442133	1.75	1259.0
2	84	5:42:08	5:38:50	24.09	420459	1.72	1240.9
3	81	5:41:20	5:29:55	23.99	407454	1.72	1235.1
4	73	7:18:18	6:55:46	24.19	511529	1.70	1230.3
5	86	6:56:02	6:44:13	24.7	491112	1.71	1266.1
6	84	6:06:53	5:51:12	24.03	442133	1.75	1259.0
7	N/A	N/A	N/A	N/A	N/A	N/A	N/A
8	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Totals & Averages	1476	98:59:11	97:55:53	25.16	7517397	1.70	1279.9


Pumps 1 and 2						
Date	Starts	Runtime	Average Current	Volume	Efficiency	Capacity
Unit:		hh:mm:ss	A	G	G/Wh	GPM
1	1	0:02:41	43.71	0	0	0
2	1	0:03:18	31.80	6190	1.97	1875.9
3	1	0:11:25	32.97	21416	1.90	1875.9
4	4	0:22:32	39.19	41535	1.57	1843.2
5	1	0:11:49	43.22	11433	1.84	1771.8
6	1	0:11:25	32.97	21416	1.90	1875.9
7	N/A	N/A	N/A	N/A	N/A	N/A
8	N/A	N/A	N/A	N/A	N/A	N/A
Totals & Averages	9	1:03:18	33.74	416020.5	1.90	1816.7

Alarms And Suspicious Events					
Name	From	To	Duration	Threshold	Other Information
Abnormal sequence	1/18/15 3:21	1/18/15 3:46	0:24:39	N / A	Multiple Pump 1 starts in a row

## Maid Devices Configurator



The Maid Device Configurator software comes with the product and is installed within the MerMaid analysis software. Within the MerMaid software the MaidDevices Configurator is located in the Tools tab section. It will also be called **Configurator** in the text.



**Maid Devices Configurator** is used to setup the following instruments:

- **EE-400** Event encoder
- **FlowMaid** level monitor and open channel flowmeter
- **PressureMaid** tap water pressure monitor
- **VOLUCALC™ Hybrid CS** Fixed and Variable Speed pump flowmeter and open channel flowmeter

### Welcome Window

The Configurator welcome window has three selections:


#### Create a new file

**Open an existing file** - for editing, modifying or viewing setup data

**Create from an existing file** - allows the user to copy parameters from a device already created. This is practical if many alarms have been created.

By default, the configuration process starts by creating a new file when **Next >** is pressed.

The **Options** link on the bottom left corner of the window is for setting up your preferred engineering units (ft, meters etc...).



## Options


Two menu tabs are available: **General** and **Units**.

The **General** tab selects the desired language. By **Default**, the Configurator will appear in the language of your computer. It is possible to change it at anytime. The application must be restarted when its language is changed.

Press the **Apply** tab to save these changes.

By default, the **Options** dialog will open on the **Units** tab.


If you select **United States**, the standard engineering for this region will be selected. It is possible to change them to fit your needs. **International** units will be metric. Press the **Apply** tab to save the changes.



## Device Details

Select Volucalc Hybrid CS, then enter the serial number of the device. This number is on the label underneath the device and also appears on the *Device Info* screen (p. 36). If the serial number is incorrect, the instrument will not be able to read the configuration associated to it.


MaidDevices Configurator file is located in the root directory of the USB drive called VHxxxx (VH with serial No.).



## General informations

The instrument's files are identified by names. The **Device Name** is used to identify the data files copied from the instrument to the USB key. The name will be useful when a USB key is used for multiple devices. If no name is given, then the serial number of the instrument becomes its name. A maximum of only 20 characters in the name can be displayed on the screen of the instrument and no special characters are permitted.

The **Power source** section defaults to AC with battery backup. The Ethernet communication option allows reconfiguring the settings for the communications with Maidmaps. Click **Next >** to continue.




The screenshot shows the 'General informations' window of the MaidDevices Configurator. It has a title bar with the application name and standard window controls. The window is divided into sections: 'Identification' with a 'Device Name' text box containing '146000' and a 'Serial number' label with value 'RT146000'; 'Power source' with radio buttons for 'AC adapter', 'AC with battery backup' (selected), 'External battery', and 'Internal batteries only'; and 'Ethernet communications' with radio buttons for 'None' (labeled 'Not connected'), 'Standard' (labeled 'Wired network'), and 'Cellular modem' (labeled 'Controlled power source'). At the bottom, there are links for 'Options...' and 'Units...', and buttons for '< Back', 'Next >', and 'Cancel'.

## Display options

In the **Regional Settings** French and English are the **Language** selections for the display and reports. The **Time Zone** is automatically adjusted to the computer's time and may be changed if required. The instrument works internally in Universal Time Coordinated (UTC), also known as Greenwich Mean Time (GMT) and will compensate for daylight savings automatically. When connected to the Internet the instrument will update the internal clock.

The **Display Brightness** can be adjusted between 0% and 100% in increments of 20%. The default value is 20%.




The screenshot shows the 'Display options' window of the MaidDevices Configurator. It has a title bar with the application name and standard window controls. The window is divided into sections: 'Regional settings' with 'Language' set to 'English' and 'Time zone' set to '(UTC-05:00) Est (É.-U. et Canada)'; 'Display' with 'Brightness' set to '20 %'; 'Battery operation' with 'Time before backlight close' set to '10 s' and 'Time before screen close' set to '30 s'; and 'Password' with a checkbox for 'Protect device with a password:' (unchecked) and a note 'A password consist of exactly 5 numbers between 1 and 4 inclusively.' Below the checkbox are fields for 'Confirm password:'. At the bottom, there are links for 'Options...' and 'Units...', and buttons for '< Back', 'Next >', and 'Cancel'.

**Battery Operation** is related to other MAID Labs' products which also use the Configurator software.

An optional **Password** is use for locking the display screen. Make a 5 numbers code with digits between 1 and 4 representing the **1**, **2**, **3** and **4** buttons of the instrument. Click **Next >** to continue.

## Lift station


This window will effect many of the following dialog windows. First select the number of pumps by clicking .

The drop down selection **variable speed**

provides choices depending on the type of pumps. The selections are variable speed, fixed speed or any mixture of the two ... if more than one pump.

If more than one pump and that there is at least one variable speed, then you must enter the pump curves for all pumps, even the fixed speed pumps.

If all pumps are fixed speed, provide the capacity of each pump and pump combinations.



**Flow algorithm** selects how the flow is calculated. If the instrument is not used for flow calculation, select **None**.

**External flow (measured)** is from an external source, such as a magnetic flow meter. The flow rate will be displayed and used for energy efficiency calculations.

**Fixed pump capacities** will allow a user to enter pump capacities if all pumps are constant speed pumps. A dialog window to enter these values will be displayed at the appropriate time.

**Pump curves** are available for all types of pumps. The advantage of the pump curve over the fixed capacity is that if the level is very high for long periods, it will use the pump curve instead of a fixed value, which will be much more accurate than a set pump capacity under these conditions.

**Volumetric** will compute inflow in the lift station based on the pump cycles. This mode is only available with fixed speed pumps.

**Volumetric with level sensor** will compute inflow with fixed speed pumps in real time at a fixed time interval or level variation. This is the most accurate way to get flow in real time.

The **variable speed pumps current** section allows for per pump, global or none selections.

**Per pump** means that there is a current sensor per pump. This is only if there are 2 pumps or less.

**Global** means that there is one current sensor for all pumps, normally placed on the electrical input of the control panel. In this case, the power consumption is distributed according to the pump flow. This is only if there are 3 pumps or less. Select **None** if there are no sensors installed.

**Electricity**

Phases:  ☐ Read all phases

Average voltage:  V ☒ Measured in delta

Power factor:

Cost per kWh:  \$

The **Electricity** section allows you to enter parameters used to calculate the power consumption of the pumps. The values are specific to the electrical configuration of each station. They are also dependent on the number and type of pumps used. The estimation of kilowatts consumed by a pump is the result of Current x Voltage x Power Factor.

If there is only one pump, then it is possible to place a current sensor per phase. In this case, ☐ **Read all phases** must be checked.

The majority of pumps used in sewer collection and water distribution systems have three phases. If this is the case, let the number of **Phases** be 3. If a current sensor is installed on only one of the 3 wires powering the pump, 3 indicates the current multiplier for estimating the total power usage of the pump. If the pump has two phases (240 volts), then choose 2 and 1 phase for most 120 volts pumps.

The **Average voltage** of the pumps is normally measured from phase to phase, which is called delta. If the voltage was measured between a phase and ground, then uncheck ☐ **Measured in delta**. Enter the average voltage of the phases on that line.

The **Power factor** is normally found on electricity bills as well as the **Cost per kWh**. These are only used to estimate the power consumption and operation cost. The last box is the currency symbol to use: \$, €, £, or ¥.

The Greenhouse gas is used to estimate the quantity of greenhouse gas generated by the lost of energy of the station based on the number of gas per watt of electricity.

Click  to continue.

## Inputs and Outputs

The **Inputs and outputs** dialog is directly related to the choices of the previous dialog relating to pumps, algorithm and current reading. Choices are normally available by clicking in the appropriate cells. This table is the best way to check all the possible combinations.

The left arrow ← means the signal is an output and to the right → means it is an input.

### Flow

The analog 4-20mA **Flow** output is proportional to the outflow calculated from the pumped curves or pump capacities. It can also include the lost water caused by an overflow event if

MaidDevices Configurator

**Inputs and outputs**  
Configure usage and sensors for each input and output.

Hardware	Function	Sensor	Range	I/O
Pump ctrl 1	Not used			Disabled
Pump ctrl 2	Not used			Disabled
Pump ctrl 3	Not used			Disabled
Pump ctrl 4	Not used			Disabled
Expansion	Not used			Disabled
→ Pump 1	Pump 1 (phase 1)	CT 75A	0 to 75 A	Pump 75 A
→ Pump 2	Pump 2 (phase 1)	CT 75A	0 to 75 A	Pump 75 A
Pump 3	Not used			Disabled
Pump 4	Not used			Disabled
← 12 VDC out	Controlled power	Controlled equipment		12 VDC
Flow	Not used			Disabled
Relay out 1	Not used			Disabled
← Relay out 2	Alarm out	Relay		Digital
→ Level	Level	Sick 6m	1.9685 to 19.685 ft, rever	4-20 mA
→ Pressure	Pump output pressure	0-100 PSI	0 to 100 PSI	4-20 mA
→ Rain	Rain	0.01" per pulse	0.01 in per pulse	Pulse
Batt. in	Not used			Disabled
> 12 VDC in	AC	AC adapter		12 VDC

Options... Units...


≤ Back Next > Cancel



calculated using one of the open channel equations. This output must first be configured by the user. The configuration window will appear by clicking the **Range** field.

In this window, **Value at 4 mA** and **Value at 20 mA** can be selected or changed with the arrows or by entering corresponding values. The user must ensure that the measurement unit shown is correct. This can be changed by clicking on the **Options** link ... All similar windows work the same way.

The 4-20 mA loop is powered by internal 12VDC. No external power is required.



Pump 1
Pump 2
Pump 3/Amp P1
Pump 4/Amp P2

The input configuration for pumps 1, 2, 3 and 4 depends on the selected number of pumps in the Lift station dialog (page 37) window and if using fixed or variable speed pumps. The table below shows the various combinations of inputs based on the number of pumps in the station with variable speed pumps.

**RPM** and **AMP** indicates the pump input is used to measure pump speed or current. Bold letters indicates this field is not optional. Italic is optional.


**RPM** is the number of pump revolutions per minute which is an output from the variable frequency drives controlling pumps. **AMP** indicates a current sensor is used to measure the pump current.

Nb of pumps	1		2		3		4	
Types of pumps	Variable	Fixed	Variable	Fixed	Variable	Fixed	Variable	Fixed
Pump 1	<b>RPM</b>	<b>AMP</b>	<b>RPM</b>	<b>AMP</b>	<b>RPM</b>	<b>AMP</b>	<b>RPM</b>	<b>AMP</b>
Pump 2			<b>RPM</b>	<b>AMP</b>	<b>RPM</b>	<b>AMP</b>	<b>RPM</b>	<b>AMP</b>
Pump 3/Amp P1	<i>AMP</i>		<i>AMP</i>		<b>RPM</b>	<b>AMP</b>	<b>RPM</b>	<b>AMP</b>
Pump 4/Amp P2			<i>AMP</i>		<i>AMP</i>		<b>RPM</b>	<b>AMP</b>

To configure the speed input of a pump, three choices are available, or **0-1000 RPM**, **0-2000 RPM** and **Custom speed**. When **Custom speed** is selected by clicking in the **Range** column, the **Custom Sensor Setup** window appears.

4-20 mA
4-20 mA
0-5 VDC
0-10 VDC
0-24 VDC

The **Hardware I/O** allows you to choose between the following analog inputs: 4-20 mA, 0-5VDC, 0-10VDC or 0-24VDC. Depending on the configuration, the user must enter the RPM relative to the measurement limits of this input.




T.C. 75A
Courant personnalisé
T.C. 150A
T.C. 15A
T.C. 300A
T.C. 75A

When recording the current is desired, selecting the Current Transformer (**CT**) is done using the drop-down menu in the **Sensor** column. The available standard sensors are in **15A**, **75A**, **150A**, **300A**, or a **Custom current**.

When a custom sensor is required, the user must enter the number of amperes corresponding to the limits of Volucalc Hybrid CS input, which is 1.5 volts.

The selected sensor is displayed in the **I/O** (input/output) column, which is **15A**, **75A** or **Alternate** for all other types of sensors. Place the pump input switches (next page) at the proper positions on the device (15A, 75A, ALT) by means of a small screwdriver or a paperclip.







**Level** The analog input **Level** is configurable in the **I/O** column. The choices are **4-20 mA**, **0-5V**, **0-10V** and **0-24V**. The choice of sensors include: **Sick 1.3 m**, **Sick 6m**, **Custom level** or **Auto-calibrate**. If Custom level is selected, the Configuration window of a custom sensor appears by clicking in the **Range** field.

By using the Function column, several functions can be assigned to this input and recorded. The most common and default feature is the **Level**.

**Auto-calibrate** is used when there is an existing sensor at the lift station and the specifications of the sensor are unknown. We specify the start and stop level of the pumps and the first time the device will be powered, it will wait for a complete pump cycle and determine automatically the configuration needed to display the same start and stop level of the already installed level sensor.

**Pressure** The analog input **Pressure** is configurable in the **I/O** column. The choices are **4-20 mA**, **0-5V**, **0-10V** and **0-24V**. This is used to read the outlet pressure for the pumps, not a single pump. The sensor ranges include: **0-100 PSI**, **0-300 PSI** and **Custom sensor**. In this case, the configuration window will appear by clicking in the **Range** field. In the Function column, several other functions can be assigned to this entry as explained in the preceding paragraph.

**Relay out 1**  
**Relay out 2** The **Relay output** can be used in different ways. As an **Alarm output**, it allows you to configure an alarm on minimum and/or maximum values. The alarm relay contacts will close when generating an alarm. The configuration of alarms is at page 23.

- Alarm out
- Manual control
- Not used
- Overflow volume
- Pumped volume
- Remote control
- Volume in

The **Remote control** function allows control of an alarm through the MaidMaps software. A connection is required to the Internet via the Ethernet port of the instrument. The bandwidth options may affect the rate at which the command is received and executed by the VS.

**Manual control** disables alarms and opens and closes the relay manually from a command entered by the user on the device.

The functions of **Overflow volume**, **Pumped volume** and **Volume in** will energize the relay contacts close for one second (create a pulse) each time the selected type of volume in the **Range** field is calculated (1 pulse = volume selected).

**Rain** The **Rain** input normally is used to record rainfall which is most common. However, it is a Digital input and can be used for other types of input selections. Some of these are **Intrusion** (alarm) and **Overflow** (float). The digital input can also record event from a pulse output meter.

- Digital input
- High level
- Intrusion
- Not used
- Overflow (float)
- Pulse input
- Rain
- Sump pump

## Fixed speed pump capacity

**Pumps**

3 fixed speed

**Flow algorithm**

☐ None

☐ External flow (measured)

☒ Fixed pump capacities

☐ Pumps curves

☐ Volumetric

In the **Lift station** dialog window, when all pumps are constant speed, the flow algorithm will use the preset pump capacities. Based on run times for each pump, the total volumes per pump and total volumes pumped (all pumps) will be calculated as outflow from the station.

The fixed or constant speed **Pump Capacities** dialog window (next) will appear two screens later, and the **Pump Curve Selection** dialog (next page) is not displayed.

The user must enter each pump capacity in the **Flow** column. Please insure the pump capacities values were taken during normal operational levels. If the capacities of pump combinations are known, then it should be entered as well.

During a drawdown procedure to calculate a pump's capacity or combination of pumps, insure the levels (Lead/Lag, Start/Stop) are the same levels used for daily operations of the station. This will provide the most accurate capacity information for the Volucalc VS.

The **Default combinations ratios** selections area provides a general rule of thumb for standard pump capacities when an actual drawdown test has not provided this information.

Note: The standard default is 1 ½ times the average pump capacity for two pumps which equals 75%. A triplex station would be 67.7% the average pump capacity. Of course these values, which

can be changed, are a general rule and do not replace an actual drawdown calculation.

**MaidDevices Configurator**

**Pumps capacities**  
Allows to specify pumps combination flows.

**Combinations flows:**

P1	P2	P3	Pumps	Flow
On	Off	Off	1	100.0
Off	On	Off	2	101.0
Off	Off	On	3	99.0
On	On	Off	1 and 2	
On	Off	On	1 and 3	
Off	On	On	2 and 3	
On	On	On	1, 2 and 3	

**Default combinations ratios**

2 pumps: 75.0 %    3 pumps: 67.7 %    4 pumps: 62.5 %

[Options...](#)    ≤ Back    Next ≥    Cancel

## Pump Curve Selection

This dialog window (next page) is used to create and select the curves for variable speed pumps.

If all pumps are identical, you can use the same pump curve as pump no. 1, check ☒ **Share curves for all pumps**. In this case, only the first pump field 1: needs to be configured.

If the pumps have different curves and have not been entered into the Configurator software, you can create new curves for each pump. The pump curve data is stored in the software and can be reused with different site files using the same pump types.

**Pump Curve Selection**  
Allows to select which pump curves to use for each curve.

Pump curves

☒ Share curves for all pumps    ☐ Impeller size    ☐ Fixed speed    ☐ Calibration

		ft	RPM	%
1:	<input type="text"/> Create...	0.000	3,450.0	100.0
2:	<input type="text"/> Create...	0.000	3,450.0	100.0
3:	<input type="text"/> Create...	0.000	0.0	100.0
4:	<input type="text"/> Create...	0.000	0.0	100.0

[Manage pumps curves...](#)

Level options

Level adjustment:  0.000 ft

Head adjustment:  0.000 ft


☐ Fixed level:  0.000 ft

Output pressure options

☐ Fixed pressure:  0.0 PSI

[Options...](#)    < Back    Next >    Cancel

The pump curves are usually provided free from the manufacturers. They represent flow rate relative to the head condition. Variable speed pumps have several curves in the graph for multiple RPM. Note: Before creating curves in the Configurator, it is important to have these curves in the computer and in a graphic format. The pump curves images should be displayed in a large format. Here is an example of pump curve : Model INTELLIFLO



Once the pump curves is found (picture above), in the Pump curves area, click [Create ...](#) for the corresponding pump and the Pump Curves Setup dialog window will appear.

Configure the units according the graph pump curve information provided, even if it is only temporarily. The Configurator will do the conversion back, when needed. To change the units, click on the [Options...](#) link.

Each pump curve created in the Configurator for a specific pump model can be reused for other pumping stations. It is important to give them a meaningful name.

The 'Pump Curves Setup' dialog box contains the following fields and controls:

- Information:**
  - Name:
  - ☒ Impeller diameter:  ft
- Chart display:**

	Minimum	Maximum	Interval	
Head:	<input type="text" value="0.000"/>	<input type="text" value="120.000"/>	<input type="text" value="20.000"/>	ft
Flow:	<input type="text" value="0.0"/>	<input type="text" value="160.0"/>	<input type="text" value="20.0"/>	GPM (US)
Initial curve speed:	<input type="text" value="3,450.0"/>			RPM
- Buttons: [Options...](#), [Advanced...](#),  ,

When the diameter of the impeller is known, it can be entered as part of the curve. If a different impeller diameter is used and entered in the Pump Curve Selection dialog (previous page), then the calculate flow will be automatically adjusted according to updated data on the impeller's diameter.

To create pump curves in the Configurator, enter the minimum and maximum values for the X-axis (flow) and Y (head) from the pump curve graph (like on the previous page) and the value for the intervals in the appropriate fields. Set a speed at which the first curve will be created in the Initial curve speed field.

The [Advanced ...](#) link will change the way curves are displayed. The best configuration is the default, which is **Cubic Spline** without any **Display options** selected.

Click  to go to the next step and the **Pump Curve Editor** window (next page) will appear.


The 'Advanced Pump Curves Setup' dialog box contains the following fields and controls:

- Pump curve type:**
- Display options:**
  - ☐ Display graphics from head (highest flow for head)
  - ☐ Reference chart (regular flow interval)
  - ☐ Display curve segments points
- Buttons:  ,

## Pump Curve Editor


The **Pump Curve Editor** provides a semi-transparent window to overlay and copy curves. Stretch the editor window over the manufactures pump curves graph and behind the pump curve editor window.


You may want to adjust the opacity of the window of the overlay screen while directly over the pump curve graph to see the data more clearly. The smaller percentage of opacity makes the window more transparent.



When overlapping the windows, be sure to use identical scales and adjust the window size for a perfect overlay of the graph of the pump curve document. Place the origin of the axes over each other to start and stretch the top and right sides of the **Pump Curve Editor**.


After the axes and intervals are properly aligned, align the pointer of the mouse to the absolute left of the curve related to the Pump speed. Double-click the mouse left button to create a first point at zero flow (the x-axis is zero) for the RPM entered in the previous screen (shown in the upper left corner of the curve editor). Create a second point in the middle of the curve and a third and final point at the end of the curve. A curve connecting the three points will be at the screen. If necessary, add additional points on the curve to an almost perfect superposition. It is possible to enter and clear head / flow points at the bottom of the curve editor.





curve, it is recommended to do a curve scan using the dotted curve created in the **Estimation** section (top right). In the **Pumps** field, enter 1 and then change the **Speed** using the arrows. The dashed curve will shift depending on the speed variation obtained with the arrows. The superposition of the dotted curve with the different curves in the graph will determine whether the addition of a second curve is required. If this is the case, the **Pump speed** section, click the **Add ...** and enter the RPM for which the second curve must be created and use the same steps as before to create the new curve.






The user will automatically return to the **Pump Curve Selection** dialog window (Page 49). It is possible to **Add**, **Modify**, **Rename** and **Delete** pump curves by clicking the [Manage pumps curves ...](#) link.

After accepting the pump curves, return to the initial screen of the **Pump Curves Selection**. These are advanced impeller settings and only used when the impeller may be worn or not the original impeller do to maintenance requirements. The setting will compensate for the impeller size, speed or calibration. These adjustments will only affect the system curve and not the pump curve you may have loaded into the software. On the right, you can enter the true diameter of the impeller.

If only constant speed pumps are used, then this does not apply.

To complete the **Pump Curves Selection** dialog, this picture is used to explain the **Level options** and **Output pressure options**.





The **Level options** allows you to enter values to compensate abnormal readings.

**Level adjustment** is the difference in height between the level 0 set (page 48) and the level of the pumps. This value should be a positive number if the pump is below the level 0.

**Head adjustment** is similar, but for the head this time. A positive number indicates that the sensor is higher than the pump.

☐ **Fixed level:** or ☐ **Fixed pressure:** is when to force a value (no sensor or faulty sensor) is needed. If no sensor is configured, it is necessary to specify the level or fixed pressure as appropriate.

## VOLUCALC™ Hybrid CS Calibration worksheet

If you do not have the curves for the variable speed pumps, then they must be created. If you have them, then you can check the system curve. The flow accuracy of the VOLUCALC™ Hybrid CS is directly proportional to the quality of the calibration performed. MAID Labs provides an Excel worksheet on the USB key or downloaded from Maid Labs' website through this link [www.maidlabs.com/Files/VS\\_Calibration\\_worksheet\\_GPM.zip](http://www.maidlabs.com/Files/VS_Calibration_worksheet_GPM.zip). It is explained on next page.

This is how the Calibration of the Volucalc Hybrid CS works:

- It takes one curve per speed, preferably low, medium and high speed, 3 speeds are required.
- Run the pumps at the each speed within a known volume.
- The start and stop levels used should be in the middle of the normal operating level for the variable speed pumps. For example: If the normal is set at 10.0' then the stop should be 9.5' and the start 10.5'.
- Manually start and stop the pumps at each level for each pump and for each

	A	B	C	D	E	F	G	H
1	<b>Volucalc VS Calibration</b>					Enter data in grey area only		
2	Name of Lift Station: <input type="text"/>							
3	Install a Volucalc VS with level and pressure sensors.							
4	Calibrate all the sensors (with Maid Devices configurator).							
5	Enter well dimensions (surface in feet)				Dim. 1:	<input type="text"/>	Dim. 2:	<input type="text"/>
6	Select start and stop levels that will be used during the tests. If possible, try to have the same distance above and below the average level at which the pumps usually operate. If the distance between the levels is too high, it will take forever to do the calibration. If the distance is too small, the accuracy will be reduced. 5 to 15 minutes fill-up time is good. Do a first fill-up cycle to calculate the average flow before the pump operation.							
7	Measure the distance between these levels.						Distance:	<input type="text"/>
8	Volume of well (ft³)		0				Gallons:	-
9	Compute all the data and create pump curves and setup this in the MaidDevices							
	Pump #	SPEED	RPM	Pump Start HH:MM:SS	Pressure	Pump Stop HH:MM:SS	Time Period HH:MM:SS	Flow Rate GPM
11								
12	1	LOW					0:00:00	
13	1	LOW					0:00:00	
14	1	LOW					0:00:00	
15	1	Intermediate					0:00:00	
16	1	Intermediate					0:00:00	
17	1	Intermediate					0:00:00	
18	1	High					0:00:00	
19	1	High					0:00:00	
20	1	High					0:00:00	
21	2	LOW					0:00:00	
22	2	LOW					0:00:00	
23	2	LOW					0:00:00	
24	2	Intermediate					0:00:00	
25	2	Intermediate					0:00:00	
26	2	Intermediate					0:00:00	
27	2	High					0:00:00	
28	2	High					0:00:00	
29	2	High					0:00:00	
30	1+2	LOW					0:00:00	
31	1+2	LOW					0:00:00	
32	1+2	LOW					0:00:00	
33	1+2	Intermediate					0:00:00	
34	1+2	Intermediate					0:00:00	
35	1+2	Intermediate					0:00:00	
36	1+2	High					0:00:00	
37	1+2	High					0:00:00	
38	1+2	High					0:00:00	
39								

< >
2 pumps GPM
3 pumps GPM
+

speed. Then enter the run time in the spreadsheet to calculate the flow rate of the pump.

- Repeat the process as many times as time allows it to generate good average results.
- Create the flow curves in the Configurator.

This is important to have the same distance above and below the average level at which the pumps usually operate. If the distance between the levels is too high, it will take forever to do the calibration. If the distance is too small, the accuracy will be reduced. 5 to 15 minutes fill-up time is good. Perform a fill-up cycle to calculate the average flow before the pump operation.

## Level setup


This window allows you to select and configure the level sensor and set the overflow level if required.

This is useful to configure the device to display the same value as an existing level sensor in the station. There is 2 methods of doing this: with the level setup windows or with the automatic calibration in the “Inputs and outputs” menu.

The level setup windows is optimized to configure a level sensor in a open channel flow meter and with a stable level.

Measure the distance between the sensor and the water level and specify the real water depth, or select a displayed zero value. Both values will update automatically when numbers are entered and on the right, there is a dynamic graphic that visually represent the configuration.

The overflow level need to be checked to record overflow events. It's also possible to configure a faster analog read interval when the device is working on battery and when the level is near the overflow level. If the “Overflow level” is set to 10ft and fast reading is set to 1ft, this means that the device, if working on battery, will start to read the analog input faster (see the read interval at the “External battery” page) when the level is over 9 ft.



## Flow computation formulas

All flow formulas have their advantages and disadvantages. Choosing the one that gives the best results given the installation's limitations is the responsibility of the user. Marcel Roche wrote in SURFACE HYDROLOGY: "Being convinced that poor measurement is better than a good calculation, you should never hesitate to measure".

### Conditions for implementation of Weirs:

- The plate must be perfectly vertical and perpendicular to the sides of the incoming channel, waterproof and crushproof.
- The incoming channel must be straight, uniform, and rectangular with a constant slope over a length greater than 10 times the width of overflowing water in the channel at maximum load.
- The water level in the downstream channel must be sufficiently below the highest point of overflowing water to ensure a free flow and be fully ventilated.

MaidDevices Configurator

Open channel flow  
Configure how to compute flow from level input.

Computation method: Contracted Rectangular Weir

Crest length of weir: 1.00 ft


Validation

Water Level h: 0.059 ft

Flow Q: 0.0305 MGD (US)  $Q = 2.1517 (1 - 0.2h) h^{1.5}$

Options... Units... < Back Next > Cancel

## Contracted Rectangular Weir and Suppressed Rectangular Weir




The accuracy of rectangular weirs, with or without contractions, is usually between 1 to 4% of the flow coefficient when all conditions are met.

The **Crest length of weir** parameter is required.

Flow computation

Method: Contracted Rectangular Weir

Crest length of weir: 1.00 ft



### *Trapezoidal Weir (Cipoletti)*



The accuracy of the trapezoidal weir or Cipoletti is the order of 1 to 4% of the flow coefficient when all conditions are met.

The **Crest length of weir** parameter is required.

Flow computation

Method: Cipoletti Weir

Crest length of weir: 2.00 ft

### *V Notch Weir*



The accuracy of the triangular weir is on the order of 1 to 2% of the flow coefficient when all conditions are met.

To maximize the chances of achieving this degree of accuracy, the distance between the base of the channel and the tip of the V should be twice the distance between the tip of the V and the surface of the water and the distance between the sides of the channel and the top of the V should be twice the distance between the tip of the V and the surface of the water. The **V angle** parameter is required.

Flow computation

Method: V Notch Weir

V angle: 90.0 degrees

### *Manning Equation (Open channel)*

This type of channel is often encountered in literature as a good to calculate flow in overflow conditions.

The **Manning Coefficient**, **Bottom width**, **Pipe slope** and **Side angle** parameters are required:

Flow computation


Method: Manning Equation (Open channel) ▼

Manning Coefficient: Unfinished concrete ▼ 0.017 ▼

Bottom width: 10.00 ▼ ft

Pipe slope: 0.50 ▼ Δy / Δx

Side angle: 45.0 ▼ degree



Unfinished concrete ▼

Clay drainage tile, smooth asphalt

Corrugated metal storm drain

Custom value

Finished concrete

Painted steel, coated cast iron

Plastic, other smooth surfaces

Smooth unpainted steel

Uncoated cast iron

Unfinished concrete

Vitrified clay sewer tile

### Manning Equation (Partially full pipe)

This equation is the easiest to use to assess the volume and flow lost in an overflow. The Manning equation is usually like this:

$$Q = \frac{KAR^{\frac{2}{3}}S^{\frac{2}{3}}}{n}$$

$Q$  = Flow Rate


$K$  = Coefficient relative to the units used in the equation

$A$  = Area of the submerged part of the pipe

$R$  =  $A$  divided by the perimeter of the submerged section

$S$  = Slope of pipe

$n$  = Coefficient representing the degree of roughness of the pipe wall.



The Manning equation is used to estimate the flow in open channel situations where it is not practical to construct a weir or channel to measure the flow with greater accuracy.

This equation was developed to calculate the flow in locations where the water flows at a speed relative to the angle of the pipe roughness and the depth of water. When water escaped from a tank, as for an overflow pipe located in pumping station, an error could be induced because the equation is not optimized for this type of installation, but it is the only one available.

The **Manning Coefficient**, **Pipe diameter** and **Pipe slope** parameters are required.


Flow computation

Method: Manning Equation (Partially full pipe) ▼

Manning Coefficient: Unfinished concrete ▼ 0.017 ▼

Pipe diameter: 1.00 ▼ ft

Pipe slope: 0.50 ▼ Δy / Δx



Unfinished concrete ▼

Clay drainage tile, smooth asphalt

Corrugated metal storm drain

Custom value

Finished concrete

Painted steel, coated cast iron

Plastic, other smooth surfaces

Smooth unpainted steel


Uncoated cast iron

Unfinished concrete

Vitrified clay sewer tile




### Parshall Weir



The Parshall weir is available in several sizes. Dimensions directly supported by the device are those in the following table. In the case where the size of the weir is not available in the table, just use the standard formula and set the parameters for the equivalent.

Parshall in inches
1"
2"
3"
6"
9"
12" (1')
18" (1,5')
24" (2')
36" (3')
48" (4')
60" (5')
72" (6')
84" (7')
96" (8')
120" (10')
144" (12')
228" (19')
240" (20')
300" (25')
360" (30')
480" (40')
600" (50')

### Palmer-Bowlus Weir



The Palmer- Bowlus Weir is available in several sizes. Dimensions directly supported by the device are those in the following table. In the case where the size of the weir is not available in the table, just use the standard formula and set the parameters for the equivalent.

Palmer-Bowlus in inches
4"
6"
8"
10"
12" (1')
15"
18"
21"
24" (2')
27"
30"
36" (3')
42"
60" (5')
72" (6')

### Leopold-Lagco Weir

The Leopold-Lagco Weir is available in several sizes. Dimensions directly supported by the device are those in the following table. In the case where the size of the weir is not available in the table, just use the standard formula and set the parameters for the equivalent.

The majority of flow formulas can be summarized in two equations, such as the standard flow and the polynomial flow equations. In both cases, the parameters must be entered according to measurements in feet and flow in cubic feet per second. The tables below are good examples :

Leopold-Lagco in inches
4"
6"
8"
10"
12" (1')
15"
18"
21"
24" (2')
30"

## Polynomial Flow Formula

The majority of the formulas of flow can be summarized in two equations, standard flow and polynomial flow. Note that the settings of the following units are in feet (ft) for the height and cubic foot (ft<sup>3</sup>) for flow.

Flow computation

Method: Polynomial flow formula

Parameter A: 0.000

Parameter B: 0.000

Parameter C: 0.000

Parameter D: 0.000

$$Q = A + Bh + Ch^2 + Dh^3$$

A, B, C and D: User defined values

Q: Flow GPM (US)

h: Water Level ft

## Standard Flow Formula

All the following tables are based on this formula, with the exception of the Polynomial formula.

We assume that the user has the knowledge to choose the most suitable Equation for the system on which the product will be installed.

Flow computation

Method: Standard flow formula

Parameter A: 0.000

Parameter B: 0.000

Parameter C: 0.000

Parameter D: 0.000

$$Q = A \times (B + Ch)^D$$

A, B, C and D: User defined values

Q: Flow GPM (US)

h: Water Level ft

### Channels

H Channel	A	B	C	D
0.50	1.60	0	1	2.2
0.75	1.77	0	1	2.23
1.00	1.95	0	1	2.30
1.5	2.12	0	1	2.30
2	2.37	0	1	2.23

Parshall	A	B	C	D
1"	0.338	0	1	1.55
2"	0.676	0	1	1.55
3"	0.992	0	1	1.55
6"	2.060	0	1	1.58
9"	3.070	0	1	1.53
12"	3.950	0	1	1.55
24"	8	0	1	1.55
36"	12	0	1	1.57
48"	16	0	1	1.58
60"	20	0	1	1.59
72"	24	0	1	1.59

Palmer-Bowlus	A	B	C	D
4"	1.73	0.00588	1	1.957
6"	2.071	0.005421	1	1.903
8"	2.837	0.01456	1	1.972
10"	2.843	0.01616	1	1.953
12"	3.142	0.017	1	1.936
15"	3.574	0.0168	1	1.906
18"	3.988	0.01875	1	1.898
24"	4.574	0.0408	1	1.950
30"	5.022	0.0625	1	1.966
36"	5.462	0.08	1	1.991

Trapezoidal	A	B	C	D
60°	1.55	0	1	2.58

Polynomial	A	B	C	D
0.4HS	-3.48e-5	2.1e-3	3.52e-1	4.40e-1
0.6HS	-7.52e-5	8.3e-3	4.02e-1	3.79e-1

### Weirs

Triangular	A	B	C	D
22.5°	0.505	0	1	2.500
30°	0.676	0	1	2.500
45°	1.028	0	1	2.500
60°	1.420	0	1	2.440
90°	2.490	0	1	2.475
120°	4.333	0	1	2.500

Trapezoidal	A	B	C	D
0.5'	1.684	0	1	1.5
1.0'	3.367	0	1	1.5
1.5'	5.051	0	1	1.5
2'	6.374	0	1	1.5
3'	10.101	0	1	1.5
4'	13.468	0	1	1.5

Rectangular	A	B	C	D
1'	3.333	0	1	1.5
2'	6.667	0	1	1.5
3'	10.00	0	1	1.5



Lookup table

When no type of weir, channel or formulas to calculate flow with reasonable accuracy, but that a flow rate proportional to the height of the liquid is known, at least at specific heights, then the Lookup table is the function to use.

Up to 100 levels with corresponding flow rates can be entered in the table. Press the \* to add a Level and corresponding Flow rate. Entered values cannot be deleted or sorted, so enter them correctly.

Flow computation

Method: Look-up table


Flow for specific levels:

	Levels (in)	Flow (GPM (US))
1	1.00	0.10
2	2.00	0.30
3	*	

Levels are relative to the specified overflow level.

California Pipe

This method measures the output of the open end partially filled horizontal pipe which will discharge freely into the air. This method is sometimes considered to be a method of trajectory. However, the measure is really based on the depth at the end of the pipe.




The Pipe diameter is required:

Flow computation

Method: California Pipe

Pipe diameter: 2.00 ft



AJOUTER LES NOUVELLES FORMULES

## Well dimensions

The well dimensions window is optional depending on the selected flow algorithm at the lift station page.

Select the geometry of the well of the station and enter the dimensions. It's possible to enter a area directly or to select, volume between levels. This way, no dimensions are required but the volume of the water between the start and the stop of each pump is needed.

The option of the well depth is optional.

The operating mode window is also an optional window depending of the selected flow algorithm at the lift station. Keep in mind that all parameters are required only if using the Volumetric flow option (without level sensor).

There is 3 basic operating mode. One start level per pump and a common stop level, one start level per pump and pump stop one level below and distinct start and stop levels per pump.


And there is many ways to enter the values depending on the measurement method.

When distance between levels is selected, the Stop of all pumps value is the distance between the stop level and the bottom of the well. If this value is unknown, simply enter 0. Same thing for the volume between levels.

Description	Volume (US gal.)	Measured
Start of second pump	7.48	from state 2
Start of first pump	7.48	from state 1
Stop of all pumps	7.48	from bottom

## External battery

The external battery analog input reading option is used when the device is working on battery backup. The device will wakeup and read the level sensor at this interval. If there is an overflow level configured at the “Level setup” page, or an alarm with the “Read analog inputs faster”, the device will wake up to read the level sensor and this specified interval.



The screenshot shows a software window titled "MaidDevices Configurator" with a sub-header "External battery" and the text "Recording options when running on external battery". Inside the window, under the heading "Analog input reading", there are two settings: "Regular Interval:" set to "0:05:00" and "Fast reading interval:" set to "0:01:00". At the bottom left, there are links for "Options" and "Units...". At the bottom right, there are three buttons: "≤ Back", "Next ≥", and "Cancel". A small icon of a blue device is visible in the top right corner of the window.

## Alarms

To view the preconfigured alarms of the device, click on **Options...** at the bottom of the page and in the Maid configurator tab, check the Predefined alarms checkbox.

It's possible to disable an alarm by unchecking the checkbox on the left.

To create a new alarm, select "Add". A new window will open.

First thing is to select an alarm type. There are 3 choices: value too high, value too low and value in undesired range.

The next step is to select on which value the alarm will be configured. Then, fill the Threshold.

### Delays section

**Initial** delay in the delays section is the time before the alarm will be generated after the value met the threshold condition.

**Final** is the delay before the alarm is considered ended after the value is not in the threshold condition.

**Mute** is the delay before it's possible to regenerate this alarm. So if only 1 alarm of this type per day is needed, it's possible to set the mute value to 24 hours.



### Options section

**Active** is used to enable or disable the alarm without having to delete it.

**Display alert** is used to show the alarm on the device screen.

**Critical** is used to flag this alarm as critical instead of a simple warning.

**Real analog inputs faster** is used when working on battery, we can force the device to wake up following the fast reading delay configured at the previous page.



**Must acknowledge to stop alarm** is used to display the alarm on the device and require a user to acknowledge it or it will always stay on top.

**Maidmaps options:**

**Send to Maidmaps** is used to enable the communication of this alarm to the Maidmaps web server or not.

**Notify user at start** will allow for a communication of the device with Maidmaps immediately when the alarm is generated to notify Maidmaps and then Maidmaps can notify the users.

**Notify user at end** is the same thing as notify user at start but at the end of the alarm.

**Relays** section.

When the alarm is active, it's possible to configure a relay output to close the contact and make an external action. But first, the relay output needs to be configured as an alarm output on the previous Inputs and outputs configuration page.

### Communication setup

The VOLUCALC™ Hybrid CS can transmit data to a Web server and be viewed in real time. The data will be displayed in the MAID Labs Technologies software known as MAID Maps.

Depending on the bandwidth quality, communication with the server will be fast or slow. In the **General** section, when **The device is connected to the Internet** is not checked, the communication will not work. This mode also disables the Ethernet module, which allows options in an "offline" mode like manually adjusting the time (page **Erreur !**


**Signet non défini.**). By checking this box, different configuration options are enabled.

The default Web server is <http://maps.maidlabs.com>. However, it is possible to use another server by checking **Use alternate server** box and supplying a valid server address running Maid Labs software MAIDMAPS.

**Send Maid Maps data** is used to send what has been read or calculated by the instrument based on the user's time frame requirements. Choices are real time to one month.


**Send data files** is used to send mostly reports based on the user's time frame requirements. Choices are 15 minutes to one month.

**Send data after important changes** means when an alarm occurs, an immediate communication will be generated to the MaidMaps server. Based on its own settings, MaidMaps might send an email to a person who can take care of the situation.



## Report Options

This option is used to filter overflow report and digital reports to ignore events shorter than the specified value and to group all event that happen during this delay.



The screenshot shows the 'Report Options' window of the MaidDevices Configurator. The window title is 'MaidDevices Configurator'. The subtitle is 'Report Options' with a description 'Allows to specify options for reports generation.' Below this, there is a section 'Flow computation and digital events reports' with a label 'Ignore events shorter than:' and a text input field containing '0:05:00'. At the bottom, there are buttons for 'Options...', 'Units...', '≤ Back', 'Next ≥', and 'Cancel'.


## Save folder

The **Destination folder** shows where configuration files are usually saved, unless someone changed this. Click [Browse...](#) to select a different one.

To configure the Volucalc Hybrid CS using the configuration file created with the MaidDevices Configurator, copy the configuration file on the root directory of a USB key.


Use a USB drive formatted with FAT16 or FAT32. The amount of files on the key influence the time to copy files.

Follow the USB instructions on page 39.





The screenshot shows the 'Save folder' window of the MaidDevices Configurator. The window title is 'MaidDevices Configurator'. The subtitle is 'Save folder' with a description 'Select folder where configuration file should be stored'. Below this, there is a 'Summary' section with fields for 'Name: 146000', 'Serial number: RT146000', and 'File name: RT146000.mlcfg'. There is a 'Save options' section with a 'Local copy:' field containing 'D:\Temp' and a 'Browse...' button. Below this is a checkbox for 'Copy on USB key:' with a 'Refresh' button. A yellow information box contains the text: 'For transfer to a Maid device, the file must be placed in the root folder of the USB thumb drive.' Below this is a checkbox for 'Send to MaidMaps' with fields for 'User name:' and 'Password:'. At the bottom, there is a button for 'Options...', 'Units...', and buttons for '≤ Back', 'Next ≥', and 'Cancel'.

### Current Sensor (MLCT75)



The Split-core current transformer MLCT75 is designed to provide a low-cost method for monitoring electrical current. Its unique hinge pressure locking mechanism enables its installation without interrupting the current supply to the pumps or equipment.

For this model of sensor, the Hybrid CS can be configured to enable a range of 0 to 15 amps and 0 to 75 amps, depending on the settings of the micro-switches.



### Current Sensors (MLCT150 and MLCT300)

The current sensors MLCT150 (150 amps) and MLCT300 (300 amps) use the latest technology in current transformers. They are designed to meet the most stringent industry requirements. All models comply with the standards IEC1010-2-032, 600V, Cat. II.

These sensors have a jaw opening of 30 mm (1.19") and can accommodate wire of 29mm (1.15"). The unique jaw facilitates attachment to the wires. They are made of polycarbonate and ultrasonically welded, in order to ensure their robustness and comprehensive and lasting reliability. The use of wound cores improves the performance of high and low end. The accuracy of each model is optimized for its current range. AC current probes for frequencies from 40Hz to 10kHz.



### 4-20 mA Isolator (MLISO420)

- Designed to isolate a 4-20 mA signal from the Volucalc Hybrid CS.
- DC current/voltage signal isolation and transmission.
- Equipment and sensors signal acquisition.
- 4-20 mA signal isolation and transfer.
- Ground-loop elimination.
- Easy to use.
- No distortion in long distance signal.
- Dimensions: 3.2 in x 1.75 in x 0.5 in (82 mm x 45 mm x 12.5 mm)
- Efficiency Grade: 0.1 / 0.2
- High precision, error and non-linearity < 0.1%
- 4-20 mA international standard current signal input and output
- 3KV isolation between input and output.
- Temperature Range:-25°C ~ +70°C
- Standard DIN Rail35 package, super slim (12.5mm).
- Multi-turn potentiometer to adjust signal output if needed.





### Panel Door Brackets (MLSUPPANEL)



A Stainless Steel bezel, laser cut to perfect size, covers the instrument's hole cutout. Stainless steel screws, washers, nuts and plastic tubular spacers are also part of the Panel door kit.


Once the instrument is fixed, connectors must be removed in order to connect wires to them. If needed, removing the instrument from the panel takes only a minute or so.



### *DIN Rail Brackets (MLSUPDIN)*

The DIN Rails brackets kit includes 2 brackets and 4 Stainless Steel screws.

Clipping the instrument on the rail is automatic. A small screwdriver is required to unclip the instrument from the rail.



## Index

\$/kWh.....	39	Connections.....	10
0-10V.....	49	Connectors.....	8
0-24V.....	49	Constant Speed Pumps.....	11
0-5V.....	49	Constant speed pumps flow meter.....	6
120 volts.....	47	Contacts.....	2
240 volts.....	47	Contracted Rectangular weir.....	58
3 wire ultrasonic level sensor.....	10	Copy User Manual.....	42
4-20 mA Isolator (MLISO420).....	69	Cost per kWh.....	15, 47
4-20 mA loop.....	48	Create a new file.....	43
4-20 mA signal isolation.....	10	Create a new File.....	13
4-20mA.....	49	Create from an existing file.....	43
4-20mA current loop.....	10	Crest length of weir.....	58, 59
Accessories Selection Chart.....	9	CSV format.....	41
Advanced ... ..	52	Current Sensor.....	69
Alarm output.....	49	Current Transformer.....	48
Alarms.....	34, 66	Current. Outflow.....	39
Alarms Report.....	40	Date & Time.....	33
Alternate.....	48	Daylight saving time.....	45
AMP.....	48	Delete File.....	37
Analog.....	34	Destination folder.....	68
Analog input.....	33	Detailed description of the Screens.....	31
Analog output test.....	38	Déversoir Leopold Lagco.....	61
Auto-calibrate option.....	16	Déversoir Parshall.....	61
Average Outflow.....	39, 41	Déversoire Palmer Bowlus.....	61
Average voltage.....	15, 47	Device Details.....	44
Bandwidth.....	33, 34, 49	Device info.....	37
Batteries.....	45	Device Info.....	44
Battery Operation.....	45	Device Name.....	45
Before going to the lift station.....	7	DevicesMAID Configurator.....	37
Bottom width.....	60	Digital.....	34
Brightness.....	33	Digital input.....	33, 40
Calibration worksheet.....	56	Digital out.....	49
California Pipe.....	63	Dimensions.....	30
Capteur de courant.....	69	DIN Rail Brackets.....	70
Cellular Modem.....	14	Display.....	33
Cellular modem power with battery backup.....	10	Display Brightness.....	45
Cipoletti.....	59	Display options.....	45, 52
Clock.....	45	Download settings.....	35
Communication.....	31, 67	Duplex Variable Speed Pumps.....	12
Communication setup.....	67	EE-400.....	43
Communication test.....	37	Electricity.....	15, 47
Configuration.....	13	energy efficiency.....	46
Configuration Menu.....	32	Estimation.....	54
		Ethernet.....	49, 67

Events Reports .....	40	Lock screen .....	38
Excel.....	41, 56	Lock screen password .....	36
External battery .....	65	Lookup table.....	63
External flow.....	15	Magnetic flowmeter.....	46
External flow (measured) .....	46	MaidDevices Configurator .....	43
Factory Reset .....	35, 37	MaidMaps .....	25
Firmware upgrade .....	35	Main Screen .....	31
Fixed level .....	56	Manage pumps curves .....	23, 55
Fixed pressure.....	56	Manning.....	60
Fixed pump capacities.....	15, 19, 46	Manning Coefficient.....	60
Fixed speed.....	46	Manning Equation (Open channel) .....	59
Fixed speed pump capacity .....	50	Manning Equation (Partially full pipe) .....	60
Float.....	49	Manual control .....	49
Flow.....	31, 38, 40, 47, 50, 53, 63	Measured in delta .....	47
Flow accuracy.....	56	Menu .....	32
Flow algorithm .....	15, 20, 46	Menu Flowchart.....	26
Flow computation formulas.....	58	MerMaid analysis software .....	43
FlowMaid.....	43	MerMaid Data .....	42
Functions.....	49	Metric units.....	44
General.....	44, 67	MLCT150.....	69
General informations.....	45	MLCT300.....	69
Global .....	46	MLCT75.....	69
Greenhouse gas .....	15	MLSUPDIN .....	70
Greenwich Mean Time (GMT) .....	45	MLSUPPANEL.....	70
Hardware I/O .....	48	Month.....	40
Head.....	23, 38	Monthly Events .....	41
Head adjustment.....	56	Monthly Overflow .....	41
I/O.....	48, 49	Monthly reports.....	41
Impeller diameter .....	21, 52	Monthly Volucalc.....	41
Info.....	40	Multiple devices.....	45
Initial curve speed.....	21, 52	Number of pumps.....	46
Input configuration.....	48	Number selection screen.....	32
Inputs and Outputs.....	47	Offline .....	67
Inputs/Outputs.....	33	Open an existing file .....	43
Installation.....	7	Open Channel Flow .....	34, 57, 59
International units .....	44	Open channel flow meter .....	6
Internet.....	45, 49	Operation mode .....	16, 18
Intrusion .....	49	Options.....	21, 43, 44, 48, 52
IP Informations.....	37	Output pressure options.....	55
Language.....	36, 44	Overflow .....	40, 49
Level.....	31, 34, 38, 49, 63	Overflow Computation .....	34
Level adjustment .....	56	Overflow level.....	34
Level options.....	55	Overflow setup .....	34
Level Override.....	36	Overflow volume .....	49
Level setup.....	33, 57	P1 to P4.....	38
Lift station.....	46, 50	Palmer-Bowlus.....	62

Panel Door Brackets .....	70	Screen Password .....	36
Parshall .....	62	Screen Reports .....	40
Password .....	46	SD Card Info .....	37
Phases .....	15, 47	Send data after important changes .....	67
Physical Specifications .....	29	Send data files .....	67
Pipe diameter .....	60, 63	Send Maid Maps data .....	67
Pipe slope .....	60	Serial number .....	37, 44
Polynomial Flow Formula .....	62	Share curves for all pumps .....	51
Power Consumption .....	39	Shutdown device .....	38
Power factor .....	15, 47	Side angle .....	60
Power source .....	45	Simplex pump station .....	11
Pressure .....	31, 38, 49	Software upgrade .....	35
Pressure Override .....	36	Speed .....	54
PressureMaid .....	43	Speed input .....	48
Product Application .....	6	Standard Flow Formula .....	62
Product Description .....	6	Standard time .....	45
Pump Capacities .....	36	Starts .....	39
Pump Curve Editor .....	22, 52, 53	Steps to create a pump curve .....	23
Pump Curve Selection .....	21, 23, 50, 51	Suppressed rectangular weir .....	58
Pump curves .....	15, 21, 46, 51, 52	System curve .....	56
Pump Curves .....	20	Table of contents .....	4
Pump Curves Setup .....	21, 52	TCP/IP MODBUS TABLE .....	27
Pump Ratio .....	36	Technician .....	36
Pump Statistics .....	39	Technician Data .....	42
Pumped volume .....	49	The device is connected to the Internet .....	67
Pumps .....	54	Time Zone .....	45
Pumps capacities .....	50	Total power usage .....	47
Pumps curves .....	20	Total volume .....	39
Quadruplex Variable Speed Pumps .....	12	Trapezoidal Weir .....	59
Rain .....	39, 49	Triplex Variable Speed Pumps .....	12
Rain Statistics .....	39	United States units .....	44
Range .....	48, 49	Units .....	13, 33, 44
Read all phases .....	47	Universal Time Coordinated (UTC) .....	45
Real Time .....	38	USB .....	40, 68
Regional Settings .....	45	Use alternate server .....	67
Registration .....	2	V angle .....	59
Relay test .....	37	V Notch Weir .....	59
Remote control .....	49	Value at 20 mA .....	48
Report Options .....	36, 68	Value at 4 mA .....	48
Reports .....	41	Variable frequency drives .....	48
Reset .....	39	Variable speed .....	46
Reset total events .....	35	Variable speed pumps .....	51
RPM .....	22, 38, 48, 53	Variable speed pumps flow meter .....	6
RT .....	38	Volucalc Hybrid CS detects problems in lift stations .....	6
Run time .....	39	Volucalc Hybrid CS saves energy .....	7
Save folder .....	68		

Volucalc VS installation.....	25	Web server .....	67
volucalcvs.hex .....	35	Weirs .....	58
Volume.....	31, 40	Welcome Window.....	43
Volume in.....	49	Well dimensions .....	18, 64
Volumetric.....	15, 18, 46	When arriving at the lift station.....	8
Volumetric with level.....	18	When configuration is ready .....	25
Volumetric with level sensor .....	15	Year .....	40
Warranty.....	3	Zero Flow.....	22



944 André-Liné street, Granby, Quebec Canada J2J 1E2

[www.maidlabs.com](http://www.maidlabs.com) 450-375-2144 [info@maidlabs.com](mailto:info@maidlabs.com)